


QUADRIE OWNERS

Manual

CAUTION!
Drives are shipped
without oil.




Sizes 4407/M4407
thru 4608/M4608
JR, JF & JSC

FALK[®]
a good name in industry

PN - 2109326

PRICE \$2.00


Gear Drive Identification



J is the basic drive identification. It can be furnished as a shaft mounted drive JR; a flange mounted drive JF; or a screw conveyor drive JSC(Size 4407 only), as illustrated below. These unique identifiers, JR, JF, & JSC, are used throughout this manual to assist you in identifying the instructions which apply to your drive arrangement.


(JR) Shaft Mounted Drive

- 1) Basic Drive
- 2) Tie Rod
- 3) TA Taper Bushing




(JF) Flange Mounted Drive

- 1) Drive With Flange
TA Taper Bushing Optional




(JSC) Screw Conveyor Drive (Size 4407 only)



- 1) Drive With Seal Housing
- 2) Drive Shaft

+ Motor Mounts



+ Backstops




+ Cooling Fans



+ Vertical Breathers



+ Trough Ends




+ Thrust Plate Kits



+ V-Belt Guards



+ TA Removal Tool



NOTE: Use a TA-Taper bushing when mounting these drives on a straight driven shaft (Hollow shaft is taper bored).

Introduction

WARRANTY — The Falk Corporation (the “Company”) warrants that, for a period of one year from the date of shipment, the product described herein will deliver successfully its rated output as indicated on the nameplate, provided, it is properly installed and maintained, correctly lubricated, and operated in the environment and within the limits of speed, torque or other load conditions for which it was sold. Such product is expressly not warranted against failure or unsatisfactory operation resulting from dynamic vibrations imposed upon it by the drive system in which it is installed unless the nature of such vibrations has been fully defined and expressly accepted in writing by the Company as a condition of operation.

WARNING: Consult applicable local and national safety codes for proper guarding of rotating members. Lock out power source and remove all external loads from drive before servicing drive or accessories.

CAUTION: Do not weld the drive housing or accessories without prior approval from The Falk Corporation. Welding on

the drive may cause distortion of the housing or damage to the bearings and gear teeth. Welding without prior approval will void the warranty.

DRIVE RATING — Operate the drive only within the horsepower and output speed for which it was selected and specified in Selection Guide 371-110 (M371-110) for the application. Refer to the nameplate for drive size, ratio and data.

FALK FACTORY REPAIR AND REBUILD — Falk wants to continue to be your primary supplier, and extend our service to you if your equipment is in the need of repair or replacement.

We are able to furnish a fast turn-around on both the quotation and rebuild. Nobody can do the job better than Falk. If you need repair on Falk products . . . just ask.

Contact your local Falk Representative or Falk Distributor for more information.

Table Of Contents

Section I — Drive Installation

Outfitting	4
Installation	6
Lubrication	8
Startup	8

Section II — Drive Service & Repair

Preventive Maintenance	9
Stored & Inactive Drives	9
Removal Of Drive	9
Drive Disassembly	11
Identifying & Ordering Parts	13
Recommended Spare Parts	13
Parts List Of Falk Part Numbers	16
Bearing Cross Reference Numbers	18
Seal Cross Reference Numbers	18

Section III — Drive Reassembly

Drive Reassembly	19
----------------------------	----

Appendix

Appendix A: Lubrication Recommendations	26
Appendix B: Backstop Installation	29
Appendix C: TA Removal Tool	33
Appendix D: Motor Mount Installation	35
Appendix E: Vertical Standpipe Installation	37
Appendix F: Modification For Non-Standard Mounting Positions	39
Appendix G: Parts Interchangeability 3000 vs 4000 Series	41
Appendix H: Retaining Rings For Bushing Nuts and Thrust Plates & Tooth Combinations For Vibrations Analysis	43
Appendix J: Drive Shaft Recommendations for Tapered Drive Shafts	44
Appendix K: Drive Shaft Recommendations Using TA Taper Bushing	45
Appendix L: Drive Shaft Recommendations Using (TCB) Kit	47
Appendix M: V-Belt Guard Installation	49
Appendix N: Electric Fan Installation	51

Section I

Drive Installation


Outfitting

1. **JR, JF & JSC** — Find the desired mounting position in Figure 1 and install air vent and magnetic drain plug (packaged separately with drive). Also note and/or mark the oil level plug location **OR** in the case of a vertical mounting, refer to Appendix E, for installation of vertical stand pipe. If the mounting angle exceeds the limitations shown in Figure 1, refer to Appendix E, to determine modifications necessary within the limits illustrated therein. **DO NOT** fill drive with lubricant at this time.


2. **JR** — The tapered bore hollow shaft is designed for use with a TA Taper bushing for mounting on a driven shaft with a straight outside diameter. The minimum and maximum driven shaft engagement, dimension **N** in Figure 2, are shown in Table 2. The minimum engagement is necessary for full bushing engagement; the maximum engagement is only if a thrust plate will be employed to remove the drive from the driven shaft (See Appendix C for preferred removal method). Shaft tolerances for driven shafts are shown in Table 1.

Figure 1

HORIZONTAL DRIVES



VERTICAL DRIVES



ANGULAR LIMITS FOR HORIZONTAL MOUNTING (ALL CLOCK POSITIONS)




TABLE 1 — Driven Shaft Tolerances – In (mm)

Shaft Diameter		Max Undersize
Over	Thru	
2.500 (63,5)	4.000 (101,6)	.006 (0,15)
4.000 (101,6)	6.000 (152,4)	.007 (0,18)
6.000 (152,4)	7.000 (177,8)	.008 (0,20)

Figure 2





TABLE 2 — N Dimension – Inches (mm) *

Drive Size	Minimum	Maximum
4407	8.38 (212,9)	12.40 (315,0)
4415	10.33 (262,4)	13.44 (341,4)
4507	10.66 (270,8)	14.53 (369,1)
4608	13.03 (331,0)	17.56 (446,0)

* The minimum engagement is necessary for full bushing engagement, the maximum engagement is only if a thrust plate will be employed to remove the drive from the driven shaft.

- a) **THIN WALL BUSHING** (with keyway slot through the bushing wall) — With the driven shaft keyway at the 12 o'clock position, slide bushing assembly onto the driven shaft, nut end first, and position the keyway slot over the shaft keyway. The bushing may have to be opened slightly to assist in installation. Insert a screwdriver into the slot in the bushing and very lightly pry open until the bushing slides onto the shaft. Insert the drive key furnished with the bushing into the shaft keyway. Proceed to Step 6.



- b) **THICK WALL BUSHING** (with separate internal and external keyways) — Insert the driven shaft key into the driven shaft keyway. If the driven shaft has an open-ended keyway, stake the keyway, Figure 3, to prevent axial dislocation of the shaft key under operating conditions. Slide the bushing assembly onto the driven shaft. The bushing may have to be opened slightly to assist in installation. Insert a screwdriver into the slot in the bushing and very lightly pry open until the bushing slides onto the shaft. Rotate the shaft so the external keyway in the bushing is at the 12 o'clock position. Then insert the drive key, furnished with the bushing, into the keyway. Proceed to Step 6.

Figure 3






Figure 4



3. **JSC(4407 only)** — Remove the output cover from the input side of the hollow shaft bore and save. Separate contents from the drive shaft kit. Install thrust plate and retaining ring in the hollow shaft, Figure 4. Insert key into drive shaft. Slide drive shaft thru the seal housing into the hollow shaft and insert the thrust plate fastener thru the thrust plate into the drive shaft. Tighten fastener to 9500 lb-in. (1 073 Nm) Reinstall hollow shaft cover. Continue outfitting based on the type of trough end seal to be installed: (a) Waste Packing Seal; or (b) Lip Seal.


- a) **WASTE PACKING SEAL (Figure 5)** — Pack seal housing with waste packing and proceed to Step 4.

Figure 5



- b) **LIP SEAL (Figure 6)** — Coat outside diameter of seal with Permatex #3 or equivalent. Carefully slide seal over drive shaft extension taking care to not damage the seal lips. Drive seal into seal housing with the spring loaded seal lip toward the trough end side of the seal housing, flush with the seal housing. Proceed to Step 4.

Figure 6



4. **JSC** — Fasten the trough end to the seal housing using the flat head hex socket cap screws included in the drive shaft kit. Refer to Table 3 for torque value. Proceed to Step 6.

TABLE 3 — (Size 4407 JSC) Trough End Fastener Size (UNC) & Tightening Torques lb-in (Nm) Non Lubricated Fasteners


2.000	2.437	3.000	3.437
.625-11UNC 2190 (247)	.625-11UNC 2190 (247)	.750-10UNC 3960 (447)	.750-10UNC 3960 (447)

5. **JF** — (NOTE: If the driven shaft has not been machined to Falk's taper bore specifications per Falk Engineering 377-140 and a straight shaft is to be utilized, refer to Falk Engineering 377-144 for instructions). If a backstop is required and was Factory installed, remove the cover from input end of hollow shaft bore and save. Install the thrust plate and retaining ring in the hollow shaft (Refer to Figure 4). Installation of internal backstops NOT Factory installed, may require removal of the mounting flange, Ref. #12, Page 14. Proceed to Step 6.

Installation

6. **JR, JF & JSC** — Refer to Figure 7 for recommended lifting method. In order to sling JR & JF as illustrated, install the tie rod fastener in the tie rod anchor brackets. Sling the drive from the fastener as shown. For vertical installation, use (3) eye bolts as illustrated. Eyebolt sizes are 1/2" (12,70 mm) for 4407/ thru 4507 and 3/4" (19,05 mm) for 4608. DO NOT remove sling until drive is secured to shaft. Before lifting the drive into position, rotate the input shaft until the hollow shaft keyway will be in position to line-up with the driven shaft key. JF proceed to Step 11; JSC to Step 12.

7. **JR** — If the drive was received with a backstop installed, the backstop must be temporarily removed to facilitate mounting when the following conditions prevail:




Ratio J05 where rotation arrow indicates Counter-Clockwise H.S. shaft rotation.

Ratio J09, J14, or J25 where rotation arrow indicates Clockwise H.S. shaft rotation.

Refer to Section II, Figure 14 for Sizes 4407 thru 4507 and remove cover Ref. #19 and backstop Ref. #5A1. For Size 4608, refer to Figure 15 and remove backstop Ref. #5A. Proceed to Step 8.

8. **JR** — Lift the drive into position and slide onto the drive shaft taking care that the driven shaft key seats into the hollow shaft keyway. DO NOT hammer or use excessive force. Refer to Figure 8 for installation of the tie rod. The exact position of the tie rod may vary within the range shown. For tie rod mountings other than shown, refer to Falk. If it is necessary to shorten the tie rod, cut the excess from either threaded end.

Figure 8 — Tie Rod Mounting Positions 6 O'Clock Mounting Position Shown



The support to which the clevis bracket is to be fastened must sustain the torque reaction shown in Table 4. The maximum load reaction through the tie rod occurs when the tie rod is located in the extreme (40°) off angle position. The magnitude of this force is reduced approximately 30% when the tie rod is mounted in the preferred position shown in Figure 8. Use Grade 5 fasteners to anchor the clevis bracket; see Table 5 for the fastener diameter and tightening torque.

TABLE 4 — Load Reaction Through Tie Rod

Drive Size	4407	4415	4507	4608
Load lbs ★	17900	21600	28600	33500
Load (N) ★	(79600)	96100	127200	149100

★ Load includes moment due to motor and motor mount with tie rod at maximum angle.

TABLE 5 — Tie Rod Clevis Bracket Fastener Tightening Torque

Drive Size	Fastener Size †	Tightening Torque – lb-in (Nm)	
		Steel Foundation	Concrete Foundation
4407	1.000-8UNC	6800 (768)	5600 (633)
4415	1.250-7UNC	12600 (1 424)	10400 (1 175)
4507	1.250-7UNC	12600 (1 424)	10400 (1 175)
4608	1.250-7UNC	12600 (1 424)	10400 (1 175)

† Grade 5 fasteners required.

Bolt the tie rod to both the clevis bracket and the drive anchor bracket and tighten the bolts until seated against the brackets. DO NOT bend the bracket as clearance between the clevis brackets and tie rod is necessary.

9. **JR** — Thread the bushing nut onto the hollow shaft one to two turns. NOTE: The bushing nut threads have been coated with an anti-seize compound at Falk. This compound should not be removed. Before re-installing a previously used nut, recoat the nut threads only with an anti-seize compound. Keep the tapered surface of the bushing and hollow shaft bore free from all anti-seize or lubricating compounds.

WARNING: Overtightening can fail the internal retaining ring. (See Appendix H, for listing of retaining rings).

- a) Preferred Method — Use a spanner (Table 6), chain or pipe wrench to tighten the bushing nut to the torque value indicated in Table 6. Tighten the setscrew on the bushing nut.

TABLE 6 — Spanner Wrench Type and Spanner Nut Tightening Torque

Drive Size	Adjustable Hook Spanner Wrench		Spanner Nut Tightening Torque lb-in (Nm)	Nut Rotation from Seated Condition
	Armstrong Tools	Williams		
4407	34-313 6 1/8"-8 3/4"	474B	4000 (452)	180
4415	34-313 6 1/8"-8 3/4"	474B	4000 (452)	180
4507	73-213 ★	CT-15-2 ★	4000 (452)	180
4608	73-213 ★	CT-15-2 ★	4000 (452)	180

★ These are chain wrenches where standard spanner wrenches are not available.

- b) Alternate Method (To be used when exact torque can not be measured.) — Use a spanner (Table 6), chain or pipe wrench to tighten the bushing nut just until the drive can no longer be moved by hand axially on the driven shaft. Loosen nut ONLY until it can be turned by hand but do not unseat the taper. Retighten the nut hand tight. Now mark a spot on the bushing nut. Next mark a spot on the driven shaft 180° from the first mark. Use the spanner wrench to tighten the nut until the two marks are aligned i.e. one half turn. Tighten the setscrew on the bushing nut.

10. **JR** — Install backstop, motor mount, motor, sheaves (Mount sheaves as close to the drive and motor housing as possible), belts and guard. Refer to Appendix D for instructions.

11. **JF (Using tapered drive shaft)** — Put key into the driven shaft. Lift drive into position and slide onto the driven shaft taking care that the driven shaft key seats into the hollow shaft keyway. DO NOT hammer or use excessive force. Secure the drive to the foundation with fasteners and torque values shown in Table 7. Next, secure the drive to the shaft with the thrust plate fastener. Refer to Table 8 for torque value. Reinstall the hollow shaft cover. Install motor mount, motor, sheaves, belts and guard. Refer to Appendix D for instructions.

12. **JSC (4407 only)** — Assemble drive to trough, using fasteners & torques given in Table 8, and install drive shaft coupling bolts per screw conveyor manufacturer's instructions. Install motor mount, motor, sheaves, belts and guard. Refer to Appendix D for instructions.

13. **JR** — When the tie rod turnbuckle is used for belt tension adjustment, position the motor so that the belt pull will be about 90° to a line through the drive input shaft and hollow shaft as shown in Figure 9. For drives where the motor is moved to adjust belt tension, mount the motor slide base so that the belt tension adjustment is approximately parallel to the belt centers. Refer to Appendix D, for instructions relative to alignment of sheaves and belts.

TABLE 7 — JF and JSC Drives — Foundation Fastener & Tightening Torque (Non-Lubricated Fasteners)


Drive Size	Fastener Size & Grade	Torque lb-in (Nm)
4407	.750-10UNC, Gr. 5	2940 (332)
4415	1.250-7UNC, Gr. 5	12600 (1 424)
4507	1.250-7UNC, Gr. 5	12600 (1 424)
4608	1.500-6UNC, Gr. 5	22100 (2 497)

TABLE 8 — Thrust Plate Fastener Data (Non Lubricated Fasteners)

Drive Size	Fastener Size & Grade ★	Torque lb-in (Nm)	Minimum Thread Depth Inches (mm)
4407	1.000-8UNCx4.00, Gr. 8	9500 (1 073)	2.75 (69,9)
4415	1.250-7UNCx4.00, Gr. 8	19150 (2 164)	2.75 (69,9)
4507	1.250-7UNCx4.00, Gr. 8	19150 (2 164)	2.75 (69,9)
4608	1.250-7UNCx4.00, Gr. 8	19150 (2 164)	2.75 (69,9)

★ Fastener lengths given are for applications using tapered (JSC type driven shafts. Other lengths may be needed for applications using tapered bushings).

Figure 9



Lubrication

CAUTION: Drives shipped without oil.

14. **JR, JF & JSC** — Refer to Appendix A for selection of lubricant. Refer to Table 9 for approximate oil capacity of drives.

15. **JR, JF & JSC** — HORIZONTAL MOUNTING

Remove air vent and oil level plug (Refer to Step 1). Fill the drive until oil shows in the oil level hole. Coat the air vent and plug threads with #3 Permatex or equivalent thread sealant before replacing.

JRV, JFV & JSCV — (VERTICAL MOUNTING) - Refer to Figure 1, Step 1.

Input Shaft DOWN — Remove the fill plug and fill with oil to level marked on the dipstick.


Input Shaft UP — Remove the oil level and fill plugs and fill until oil shows in the oil level hole.

Coat the plug threads with #3 Permatex or equivalent thread sealant before replacing.

If stand pipe is used as oil fill, the intermediate cover plug must be removed to eliminate entrapped air.

16. **JR, JF & JSC** — Where applicable, pump grease into the input seal cover, Figure 10, until the grease appears at the shaft. Wipe off excess grease from the shaft. DO NOT use grease where it could contaminate the product e.g. foods, drugs etc.

Figure 10



Start Up

17. **JR, JF & JSC** — Before operating the drive, check any fasteners, pipe plugs, air vent, etc. which may have been loosened in the course of Outfitting, Installing and Lubricating the drive, to be sure that they have been properly retightened. Check correct rotation of motor & backstop and be sure drive is properly lubricated. After one week of operation repeat check of all external fasteners and pipe plugs.

18. After one month of operation:

- a) Operate the drive until the sump oil reaches normal operating temperature. Shut the drive down and drain immediately.
- b) Immediately flush the drive with an oil of the same type and viscosity grade as the original charge (warmed to approximately 100°F in cold weather). Rapidly pour or pump a charge equal to 25-100% of the initial fill thru the drive, or until clean oil flows thru the drain.
- c) Close the drain and refill the drive to the correct level with new or reclaimed oil of the correct type and viscosity. If determined to be in good condition by the supplier, drain oil may be reused if it is filtered thru a 100 micron or finer filter.

TABLE 9 — Approximate Oil Capacity – Gallons (Liters) ★

Drive Size	JR, JF & JSC	JRV & JFV
4407	4.3 (16,3)	6.3 (23,8)
4415	7.0 (26,5)	9.5 (36,0)
4507	10.3 (39,0)	13.3 (50,3)
4608	25.0 (94,6)	31.3 (118)

★ Quantities are approximate. Always fill drive to specified level.

Section II

Drive Service & Repair

Preventive Maintenance

PERIODICALLY — Carefully check the oil level of the drive when it is stopped and at ambient temperature, add oil if needed. If the oil level is above the specified level, have the oil analyzed for water content. Moisture in the oil may indicate seal leakage or condensation. If so, correct the defect immediately and change the oil. **DO NOT** overfill or oil leakage may result. On vertical shaft drives, remove fill plug before filling or checking oil level. If a drive is equipped with a fan, periodically clean accumulated foreign matter from the fan and fan guard to allow adequate air flow.

GREASE PURGED SEALS — Periodically (at least every six months), depending upon the frequency and degree of contamination, purge contaminated grease by pumping fresh bearing grease through the seal cage until it flows out along the shaft. Wipe off the purged grease.

Oil Changes

PETROLEUM LUBRICANTS — For normal operating conditions, change oil every six months or 2500 hours, whichever occurs first. If the drive is operated in an area where temperatures vary with the season, change the oil viscosity to suit the temperature. Where applicable, grease seals when changing oil. Refer to Appendix A.

SYNTHETIC LUBRICANTS — Synthetic lube change intervals can be extended to 8000-10,000 hours based on operating temperatures and lubricant contamination. Laboratory analysis is recommended for optimum lubricant life and drive performance. Change lube with ambient temperature change, if required. Refer to Appendix A.

Stored & Inactive Drives

NEW DRIVES WHICH HAVE NOT BEEN OPERATED — Each drive is spin tested with a rust preventive oil that will protect internal parts against rust for a period of 4 months in an outdoor shelter or 12 months in a dry building after shipment from Falk.

If a drive is to be stored or inactive beyond the above periods, spray all internal parts with a rust preventive oil that is soluble in lubricating oil or add 1 ounce (0,030 liters) of "Motorstor" ★ vapor phase rust inhibitor oil. Seal air vent immediately with pressure sensitive tape.

Before operating drives which have been stored or inactive, remove tape and fill to the proper level with oil meeting specifications given in the Lubrication Recommendation found in Appendix A.

★ Product of the Daubert Chemical Company, Chicago, Illinois. (Formerly known as "Nucl Oil.")

SHUTDOWN OF NEW OR EXISTING DRIVES WHICH HAVE BEEN OPERATED

— If a drive is to be stored or inactive for more than 2 months after a period of operation, add 1 ounce (0,030 liters) of "Motorstor" ★ to the oil sump and immediately seal the air vent with pressure sensitive tape. It is not necessary to drain the oil prior to storage if oil is still serviceable and not contaminated.

Before operating drive, remove tape and check oil level.

PERIODICALLY INSPECT STORED OR INACTIVE DRIVES AND SPRAY OR ADD RUST INHIBITOR EVERY SIX MONTHS, OR MORE OFTEN IF NECESSARY. INDOOR DRY STORAGE IS RECOMMENDED.

Drives Ordered for Extended Storage can be treated at Falk with a special preservative and sealed to rust-proof parts for periods longer than those stated above, if specified on the order.

Repair & Replacement

WARNING: Consult applicable local and national safety codes for proper guarding of rotating members. Lock out power source and remove all external loads from drive before servicing drive or accessories.

NOTE: Only the seals on the input side of the drive can be replaced without removing the drive from the driven equipment (Steps 5 thru 8). All other repairs require removal of the drive from the driven equipment (Steps 1 thru 4).

Removal

See note above if only seal replacement is to be attempted.

1. **JR, JF & JSC** — Drain the lubricant at this time. Remove safety guards and belts (motor and motor mount, optional). Remove backstop (if so equipped) when:

Ratio J05 where rotation arrow indicates Clockwise H.S. shaft rotation.

Ratio J09, J14, & J25, where rotation arrow indicates Counter-Clockwise H.S. shaft rotation.

Refer to Section II, Step 10, for backstop removal instructions.

WARNING: Drive must be supported during removal process. Use a sling around the motor mount or as recommended in Section I, Step 6. Take up the slack in the sling before proceeding.

2. **JR** — Refer to Appendix C, for instructions for using the TA torque assist removal tool.

ALTERNATE METHOD — Loosen the setscrew on the bushing nut which is located at the output end of the hollow shaft. Use a spanner, pipe or chain wrench to loosen the bushing nut (Section I, Table 6). Initially, the nut will freely rotate counter clockwise approximately 180° as the nut moves from the locked position to the removal position. At this point anticipate resistance which indicates unseating of the bushing. Continue to turn the nut until it is free from the hollow shaft. Prepare drive for lifting (Figure 7, Page 6) by disconnecting the tie rod at the drive end. Slide the drive from the bushing. The bushing can be left in place or removed, as required. If bushing will not slide off of the shaft, insert a small prybar into the split of the bushing and pry the split open slightly to loosen the bushing and remove from the shaft. For replacement of seals only proceed to Step 5, otherwise Step 9.


3. **JF** — Remove the output shaft cover, Ref. #14 (Figure 14, Page 14), from the input end of the hollow shaft. Remove the bolts which fasten the mounting flange to the driven equipment.

Remove the fastener, retaining ring, and thrust plate from the hollow shaft. Refer to Table 10 and select a backing bolt and flat washer and install them into the drive shaft as illustrated in Figure 11. The bolt head provides a working surface for the removal bolt. Reinsert the thrust plate and retaining ring into the hollow shaft and select a removal bolt from Table 10. Thread the removal bolt into the thrust plate until it contacts the backing bolt head. Torque the removal bolt to the value shown in Table 10. (If the thrust plate rotates in the shaft, align the slot in the plate with the hollow shaft keyway and insert a screw driver or piece of key stock to prevent rotation of the plate). After torquing the bolt, as instructed, strike the bolt, sharply with a hammer and retorquing the bolt if separation of the drive from the shaft did not occur. Repeat this procedure, retorquing the bolt after each blow, until separation occurs.

TABLE 10 — Removal & Backing Bolt Size and Length – Inches

Drive Size	Removal Bolt Size & Minimum Length	Maximum Tightening Torque – lb-in (Nm)	Backing Bolt Size & Maximum Length
4407	1.125-7UNC x 3.00	8900 (1 006)	1.000-8UNC x 2.50
4415	1.500-6UNC x 3.75	22100 (2 497)	1.250-7UNC x 2.75
4507	1.500-6UNC x 3.75	22100 (2 497)	1.250-7UNC x 2.75
4608	1.500-6UNC x 3.75	22100 (2 497)	1.250-7UNC x 2.75

Figure 11



CAUTION: Failure to follow this procedure may result in the destruction the threads in the thrust plate. (If the retaining ring becomes damaged, refer to Appendix H, for replacement information).

Proceed as follows:

JF to Step 5 for replacement of Quadrive seals only OR Step 9 for drive disassembly procedure.

4. **JSC (4407 only)** — Prepare drive for lifting as shown in Figure 7, Page 6. Remove drive from driven equipment trough end by removing the trough end mounting screws from seal housing. Remove coupling bolts from drive shaft and slide drive with drive shaft away from the driven equipment.

To remove drive shaft from the drive, remove the output shaft cover, Ref. #14 (Figure 14, Page 14), from the input end of the hollow shaft and then refer to Step 3 above. The procedure to separate the JSC drive from the shaft is the same as for separation of a JF drive from driven equipment shaft.

After separation of the drive and shaft has been achieved, determine the type of seal equipped in the seal housing. If it is a waste packing seal, remove the waste packing material and then remove the loosened drive shaft from the seal housing side of the drive. If equipped with a lip seal, first remove the lip seal following the removal instructions from Step 5 below. After seal is removed from seal housing, remove the loosened drive shaft from the seal housing side of the drive.


CAUTION: The seal housing acts as the bearing cage, therefore, NO NOT remove from the drive unless complete drive disassembly is anticipated. Removal of the seal housing will require readjustment of the L.S. bearings (Section III, Page 21).

DRIVE DISASSEMBLY — (Refer To Parts Drawing Figure 19)

Prior to initiating any disassembly or repair, clean accumulated dirt and grime from the surface of the drive housing. Clean the exposed portion of the input and output shafts with a solvent and a non-abrasive cloth. If the seals only are being replaced proceed to Step 5. If the drive will be disassembled for inspection or repair, skip to Step 9.

CAUTION: Do not damage shaft; new seals will leak if seal contacting surface is marred. Do not use abrasive material on shaft seal contacting surface.

Figure 12



5. SEAL REMOVAL — (When drive is to be disassembled, skip to Step 9, Page 12.) Replacement is recommended. When removing seals, maintain shafts in a horizontal plane to prevent any foreign matter from falling into the drive bearings. Drain oil from drive. Refer to Figures 12, 13, 14 & 15.

Input Seals — Seals can be replaced without removing the drive from the driven shaft. However, the seal cage must be removed to access the seal.

Sizes 4407-4507 — Remove seal cage, Ref. #21, and save shim-gaskets, Ref. #31, for reference when reassembling. Drive out old seal from seal cage. Scrape old Permatex from bore exercising caution not to score the bore.

Size 4608 — Remove seal cage, Ref. #38, and save shim-gaskets, Ref. #39, for reference when reassembling. For H.S. seal removal on drives having a cooling fan or backstop, first remove the accessory and then remove the seal cage, Ref. #63 or #66. Save shim-gaskets for reference.

All Sizes — Drive out old seal from seal cage. Scrape old Permatex from the bore exercising caution not to score the bore.


Output Seals (Figures 14 & 15) — Drive removal from driven equipment may be necessary. Refer to removal instructions, Section II, Page 9.

After dismantling drive from driven equipment, remove the output shaft cover, Ref. #14, on Sizes 4407-4507. NO NOT remove seal cages, Ref. #11 or #12, Sizes 4407-4507, and Ref. #22 or #27, Size 4608. Removal of these cages will require readjustment of the bearings (Section III, Page 21).

Refer to Figures 12, 13, 14 & 15 and remove seals as follows:

- a) Clean shaft extension with solvent and remove all sharp edges. Use a sharp center punch to lightly punch the seal case as a guide for the drill. NOTE: DO NOT drive seal into the bore too deep. Seals are not axially retained and disassembly of the drive may be required if the seal is driven too deep.
- b) Wrap several turns of tape around a .125" (3mm) diameter drill approximately .250" (6 mm) from the drill point to prevent the drill from entering too deeply into the housing and damaging the bearing. Grease or magnetize the drill to help retain the chips. Drill two .125" (3 mm) diameter holes in the seal case 180° apart. Control the angle of the drill as illustrated in Figure 13 to prevent damage to the shaft.
- c) Insert two #10-.750" sheet metal screws into the seal case leaving .500" of the screw protruding above the seal face. DO NOT drive the screw more than .250" (6 mm) beyond seal face or bearing damage may occur. Use a claw type pry bar under the screw head as shown in Figure 13 and lift the seal out. Remove all chips. Use a magnet to remove the chips that fall into the bore. Flush the drive to remove chips from the bearing. Remove Permatex from the housing bore.

Figure 13



6. **SEAL SURFACE CONDITION** — Carefully inspect polished surface of shaft where the seal makes contact. If the seal surface shows any sign of a nick, scratch, spiral swirl or groove, the shaft should be replaced or refurbished to prevent leakage of the lubricant. (In many instances the seal surface can be restored by use of a thin wall wear sleeve. Check with your local seal supplier and follow the manufacturer's instructions for installing the wear sleeve).

7. **SEAL INSTALLATION**

CAUTION: Protect seal lips from sharp edges of the keyway by wrapping thin strong paper around the shaft and coating the paper and seal lips with grease before sliding the seal on or off the shaft. Do not expand the seal lips more than .030" (0,75 mm) diameter.

- a) Install seals into seal cages where cages must be removed from drive:

4407-4507; All types, H.S. seals.
4407 JF & JSC; L.S. seals (output side).
4608; All types, H.S. & L.S. seals.

Coat O.D. of seal with Permatex #3 or equivalent sealant. Position seal squarely in seal cage with spring loaded lip toward drive. Drive or press seal into cage using a flat faced tool until seated. If drive was not disassembled, select new shims(Ref. #31 or 24, Sizes 4407-4507; Ref. #39 or 23, Size 4608) from shim kit, Ref. #100, to match those removed in Step 5.

If drive was disassembled, install the complete seal cage shim pack (Ref. #31 or 24, 39 or 23). Carefully slip seal cage with seal over the shaft. Replace fasteners and cross tighten to torques listed in Table 14, Section III. Reset axial float per instructions in Section III, Page 21.

- b) Install seals into seal bores where seal cages may remain attached to housing:

4407 JF & JSC; L.S. seals (input side).
4407-4507JR; L.S. seals (input & output sides).
4415-4507JF; L.S. seals (input & output sides).


Coat O.D. of seal with Permatex #3 or equivalent sealant. Carefully slip seal over shaft and position squarely in seal bore with spring loaded lip toward drive. Use a cylindrical square faced tool to drive or press seal into bore until outer seal wall is seated 0.14" (3,5 mm) inside the seal bore outer wall.

CAUTION: DO NOT seat seal against bearing; a shoulder is NOT provided for stopping the seal. Measure seal axial runout with a dial indicator mounted on the shaft. If the seal axial runout is more than 0.010" (0,25 mm), tap high side of seal with installation tool until seal axial runout is 0.010" (0,25 mm) or less.

8. **DRIVE REPAIR IS COMPLETE** — Review instructions in Section I for reassembly of drive onto driven shaft.

Drive Disassembly — Continued

9. When seals, Ref. #21 & 23 (4407-4507); Ref. #21, 37 & 64 (4608), are to be reused (Replacement is recommended), wrap the input shaft keyway and output shaft threads with masking tape or light weight kraft paper to protect seal lips during disassembly. Cover wrapping with a light coat of grease.
10. Remove backstop parts if so equipped. For Sizes 4407, 4415J14 & 4507J14 remove cover Ref. #19, backstop Ref. #5A and appropriate spacers & retaining rings from backstop cage. Re-install cover and finger tighten fasteners. For Sizes 4415J25 & 4507J25, remove entire backstop cage. Disassemble retaining rings and remove backstop. Re-install cage and cover without the backstop and finger tighten fasteners. (For all drives, note direction of rotation of input shaft for proper reassembly.)
11. Lay drive on bench with input shaft up. Remove housing cover fasteners, Ref. #33, Sizes 4407-4507; Ref. #13, Size 4608. Screw eyebolts into tapped holes (5/8 - 11UNC, Sizes 4407-4507; 3/4 - 10UNC, Size 4608) diagonally opposite in cover plate. Eyebolts can be used to jack the cover off the dowels. Attach hoist cables and lift cover plate off housing base.
12. Remove the shaft assemblies (J05 = 3A & 4A, J14 or J25 = 1A, 2A & 4A) from output housing, Ref. #10, using eye bolts for the high speed shaft and low speed pinion assemblies (3/8 - 16UNC Sizes 3407 - 3507; 1/2 - 13UNC Size 4608). All low speed shaft assemblies can be lifted by slinging through holes in the gear web.
13. Turn housing on either narrow side. If tapered roller bearings are being replaced, remove end covers and seal cage from output side of drive and drive bearing cups through the bores. Remove bearing cups from the housing cover in the same manner.
14. Drive seals out from base and cover bores and seal cages if replacement is indicated. Remove gasket material, seal compound and any accumulated foreign matter from seal joints, bores and adjacent sealing surfaces. Use a solvent to clean out the housing covers and shaft assemblies.
15. If drive is equipped with an internal backstop, check the shaft surface and the backstop sprags (inside diameter) for signs of wear. If either component shows evidence of wear, both should be replaced (Assemblies Ref. #1A and 5A). Also refer to Step 6 for inspection of seal surfaces.

16. Inspect gear teeth for wear or indications of fatigue, e.g. hairline cracks at the root of the tooth. If one element has undergone severe wear or broken teeth, replace the mating element also.
17. Clean and inspect bearings for wear. Lubricate with light oil before spinning to avoid scoring of working surfaces. Remove any worn bearings with a wheel puller. If tapered roller bearings are being replaced, drive the bearing cups out of the housing base and cover, Ref. #10. DO NOT use new cone assemblies with worn (old) cups.
18. If gears are to be replaced, use a wheel puller or press to remove gears Ref. #1A4 or 4A4 from their shaft. Exercise caution to avoid scoring shaft seal diameter with the keyway in the gear.
19. Inspect all fasteners for damage or wear and replace with fasteners of equal grade. Grade 5 fasteners have three (3) radial lines on the head. Fasteners are available in kit form, Ref. #80. 
20. If the shaft assemblies can be reused intact (no new parts required), refer to Section III, Steps 6 thru 8, for reassembly procedure. Replace all shim-gaskets with new parts, Kit Ref. #100. Use the same thicknesses as removed during disassembly.

Identifying & Ordering Parts

1. Refer to the parts diagram, Figures 14 or 15, and make a list of the parts required by part reference number. For example, Ref. #21, 23, 100, 1A, 2A1, and 2A2. When a gasket joint is separated, always replace with new shim-gaskets. Order Ref. #100 shim-gasket kit.
2. Now refer to the parts list, Table 11, and determine the part description and Falk part number using the part reference number (Step 1) and the drive identification (e.g. 4407J25) in the column headers of the parts list.
3. Use the part description and Falk part number to order the required parts. In the examples of preceding Steps 1 and 2, Ref. #21, 23, 100, 1A, 2A1 and 2A2 for a 4407J25, parts would be ordered as follows:
 - Ref. #21 — Seal cage 4723117
 - Ref. #23 — Seal 0912913
 - Ref. #100 — Shim-gasket kit 4723120
 - Ref. #1A — Shaft assembly with gear 4723133
 - Ref. #2A1 — Bearing 0921780
 - Ref. #2A2 — Bearing 0921780
4. Tables 12 and 13 converts Falk part numbers to bearing and seal manufacturer's part numbers. Tooth combinations are listed in Appendix H.
5. Place your order with your local Falk Distributor. If you need to locate a distributor, phone (414) 342-3131.

Recommended Spare Parts

1. For non-critical drive applications a complete set of bearings, seals and shim-gaskets is recommended. If stored in their original packaging in a dry, cool location, these parts have a minimum shelf life of 5 years.
2. For critical drive applications (where an outage would create a major production loss), a complete drive is recommended.




Figure 14 — Sizes 4407 thru 4507




Figure 15 — Size 4608




TABLE 11 — Parts List Of Falk Part Numbers

Ref. No.	Part Description	Drive Size		
		4407	4415	4507
Housing Components - J05, J14 & J25				
11	Seal Cage	0352865	0344480	0344425
12	Flange – Seal Housing	0352889
12	Mounting Flange	...	0426963	0426935
14	Shaft Cover	2110604	4723140	4723160
15	Shaft Cover	4723114	4723163	4723163
16	Shaft Cover	4723114	4723142	4723164
17	Shaft Cover - Type J05	4723115	0344426	0344426
18	Shaft Cover - Type J14 & J25	2110747	0344426	0344426
19	Shaft Cover - Type J14 & J25	1219672	0344428	0344428
20	Backstop Cage - Type J14	1231142	0344429	0344429
20	Backstop Cage - Type J25	1231142	0344427	0344427
21	Seal Cage	4723117	4723144	4723165
22	Seal	2912056	0912765	0912742
22	Seal, 4407JF, JSC, Seal Hsg. Side	2912098
23	Seal	0912913	0912913	0912858
40	Tie Rod Anchor Assembly	0757211	0712831	0712831
41	Air Vent	0914088	0914088	0914088
80	Fastener Kit - Includes Ref. #33 thru 39 & 42	4723119	4723145	4723166
100	Shim-Gasket Kit - Includes Ref. #24 thru 32	4723120	0758580	0758587
Rotating Elements - J05				
3A	Shaft Assembly - Includes Ref. #3A1 - 3A4	4723121	4723146	4723167
3A1	Bearing	0921855	0921494	0921752
3A2	Bearing	0921863	0921859	0921858
3A3	Pinion & Shaft - Includes Ref. #3A4	4723122	4723147	4723168
4A	Shaft Assembly - Includes Ref. #4A1 - 4A5	4723124	4723150	4723170
4A1	Bearing	2905186	0921861	0921755
4A2	Bearing	2905186	0921861	0921755
4A3	Hollow Shaft - Includes Ref. #4A5	4723125	4723149	4723171
4A4	Gear	1231140	1231313	1231353
6A1	Fan	4723126	4723126	4723172
6A3	Guard	4721426	4721426	4723173
6A4	Grill	4723127	4723127	4723174
Rotating Elements - J14				
1A	Shaft Assembly With 1A4 Gear	4723128	4723151	4723175
1A	Shaft Assembly Without 1A4 Gear	4723129	0758575	0758582
1A1	Bearing	0921682	0921529	0921752
1A2	Bearing	2915106	0921860	0921858
1A3	Pinion & Shaft - Includes Ref. #1A5	4723130	4723152	4723179
1A4	Gear	1219666	1220256	1220136
5A	Backstop Assembly - Includes Ref. #5A1 - 5A4	4723132	4723153	4723153
Rotating Elements - J25				
1A	Shaft Assembly With 1A4 Gear	4723133	4723154	4723176
1A	Shaft Assembly Without 1A4 Gear	4723134	0758576	4723178
1A1	Bearing	0921349	0921494	0921752
1A2	Bearing	2915107	0921859	0921857
1A3	Pinion & Shaft - Includes Ref. #1A5	4723135	4723155	4723180
1A4	Gear	1219665	1220258	1220138
5A	Backstop Assembly - Includes Ref. #5A1 - 5A4	4723132	4723156	4723156
Rotating Elements - J14 & J25				
2A	Shaft Assembly - Includes Ref. #2A1 - 2A4	4723137	4723157	4723182
2A1	Bearing	0921780	0921556	0921752
2A2	Bearing	0921780	0921556	0921530
2A3	Pinion & Shaft - Includes Ref. #2A4	4723138	4723158	4723183
4A	Shaft Assembly - Includes Ref. #4A1 - 4A5	4723124	4723150	4723170
4A1	Bearing	2905186	0921861	0921755
4A2	Bearing	2905186	0921861	0921755
4A3	Hollow Shaft - Includes Ref. #4A5	4723125	4723149	4723171
4A4	Gear	1231140	1231313	1231353
6A1	Fan	4723126	4723126	4723172
6A3	Guard	4721426	4721426	4723173
6A4	Grill	4723127	4723127	4723174

Continued on next page

TABLE 11 — Parts List Of Falk Part Numbers (Continued)

Ref. No.	Part Description	Unit Size
		4608
Housing Components - J25		
17	Air Vent	0720000
21	Seal	0912768
22	Seal Cage	4723185
27	Mounting Flange - Type JF	4723190
30	Shaft Cover	4723192
37	Seal	0912758
38	Seal Cage	4723186
63	Seal Cage	4723187
64	Seal	0912757
65	Shaft Cover	0284960
66	Seal Cage	4723188
67	Yoke	4723194
80	Fastener Kit - Includes Ref. #11,13,18,24,31 & 40	4723195
100	Shim-Gasket Kit Includes Ref. #12, 23, 29 & 39	4723196
106	Tie Rod Anchor Assembly(JR only)	0712831
Rotating Elements - J25		
1A	Shaft Assembly With 1A4 Gear - Without Fan or Backstop	4723197
1A	Shaft Assembly With 1A4 Gear - With Fan or Backstop	4723198
1A	Shaft Assembly Without 1A4 Gear - Without Fan or Backstop	4723199
1A	Shaft Assembly Without 1A4 Gear - With Fan or Backstop	4723200
1A1	Bearing	0921751
1A2	Bearing	0921752
1A3	Pinion & Shaft - Unit Without Fan or Backstop	4723201
1A3	Pinion & Shaft - Unit With Fan or Backstop	4723203
1A4	Gear	0352892
2A	Shaft Assembly - Includes Ref. #2A1 - 2A5	4723205
2A1	Bearing	0921352
2A2	Bearing	0921352
2A3	Pinion & Shaft - Includes Ref. #2A5	4723207
2A4	Spacer	1231228
4A	Shaft Assembly - Includes Ref. #4A1 - 4A6	4723209
4A1	Bearing	2905910
4A2	Bearing	2905910
4A3	Hollow Shaft	4723210
4A4	Gear	0352893
4A5	Spacer	1231229
5A	Backstop	0755442
6A1	Fan	4723214
6A2	Bushing	4723215
6A3	Guard	4723173
6A4	Grill	4723216
6A10	Shaft Guard	4723217
6A11	Deflector	0294866

TABLE 12 — Bearing Cross Reference Numbers

Falk Part Number	Manufacturers Number
Tapered Roller Bearings *	
921349	HM212046/HM212011
921352	6580/6535
921494	H715336/H715311
921529	H715345/H715311
921530	H414249/H414210
921556	H715332/H715311
921682	HM212049/HM212011
921751	JH217249/JH217210
921752	JH415647/JH415610
921755	JM736149/JM736110
921780	HM212044/HM212011
921855	5584/5535
921857	65212/65500B
921858	65237/65500B
921859	65200/65500B
921860	65225/65500B
921861	67782/67720
921863	5565/5535
2905186	LM330448/LM330410
2905910	LM742749/LM742710
2912058	HM807040/HM807015B
2912059	HM807035/HM807015B

* Falk suppliers of Tapered Roller Bearing are: Timken, Bower and Tyson.

TABLE 13 — Seal Cross Reference Numbers

Falk Part Number	Manufacturers Number †	
	Chicago Rawhide	National
912742	70080	477436
912757	...	417316
912758	29906	...
912765	64993	...
912768	85014	...
912858	29317	416654
912913	24898	471271
2912056	60004	...

† Subject to substitution of equivalent seals without notice.

Section III

Drive Reassembly

Refer To Parts Drawing Figures 14 & 15.

1. GENERAL

a) Clean all parts to be reassembled and coat all taper roller bearing cups and pinion teeth with oil. DO NOT lubricate gear teeth prior to assembly on shaft.

b) Heat all tapered roller bearing cones in an oven to 275°F(135°C).

CAUTION: Do not apply flame directly to bearings or rest bearings directly on a heated surface.

c) Slide or press all bearing cones tight against the shoulder or spacer.

CAUTION: Do not apply force to the bearing outer race. Apply force against the inner race only.

2. ASSEMBLY OF ROLLER BEARING CUPS — Where bearings will be reused and where bearing cups were not removed from the housing, skip to Step 3. It is recommended that bearings be replaced when ever drive is disassembled after being in service.

Install bearing cups only in housing base at this time. Coat bearing cups and housing bores with an SAE 20(or heavier) oil and drive or press cup squarely into the housing bores until positioned as shown in Figure 16 and 17. Use a flat plate and a brass bar to avoid damaging the bearing cups.

Figure 16





Figure 17



NOTE, that the exact positioning of the bearings in the bores will be achieved during the bearing adjustment procedure in Step 6.

CAUTION: Take care not to allow cups to cock during their installation as this could result in permanent damage to housing.

If cups become cocked in the bores, tap the high side lightly to re-position.

3. ASSEMBLE SEAL CAGES TO HOUSING OUTPUT SIDE (BASE) AS FOLLOWS:

a) Turn housing on work bench to its side being careful that the bearing cups do not fall out of the bores. Assemble low speed seal cage without seal and one .015" (0,38 mm) shim-gasket, Ref. #11 or 12 and 24 for Sizes 4407 - 4507 & Ref. #22 or 27 and 23 for Size 4608. Cross tighten fasteners, Ref. #34 for Sizes 4407- 4507 & Ref. #24 for Size 4608, to torque specified in Table 14.

Check to be sure that cages and covers are registered on the bearing cups to avoid hanging up of the cups.

TABLE 14 — Fastener Tightening Torques

Fastener Size — Inches	.375-16	.500-13	.750-10	.750-10	.875-9
Tightening Torque lb-in (Nm)*	330 (37)	825 (93)	3960 (447)	Size 4608: 2940 (332) All Others 3960 (447)	6400 (723)

*Torques are for non-lubricated fasteners.

b) Assemble intermediate end cover and one .015" (0,38 mm) shim-gasket, Ref. #15 and 25 for Sizes 4407 - 4507 & Ref. #29 and 30 for Size 4608. Cross tighten fasteners, Ref. #35 for Sizes 4407- 4507 and Ref. #31 for Size 4608, to torque specified in Table 14.

c) Assemble high speed pinion shaft cover or seal cage without seal as follows:

Size 4407 - 4507 without backstop — Shaft cover, one .015" (0,38 mm) shim-gasket and cross tighten fasteners to torque specified in Table 14. (Ref. #17, 27 and 37 for Type J05 & Ref. #18, 28 and 37 for Type J14 & J25).

Size 4407- 4507 with backstop — Backstop cage, shaft cover, shim-gaskets and finger tighten the fasteners, Ref. #19, 20, 29, 30 and 38. The backstop will be installed following assembly of shaft assemblies into drive housing.

Size 4608 without backstop — Shaft cover, one .015" (0,38 mm) shim-gasket and cross tighten fasteners to torque specified in Table 14, (Ref. #39, 40 and 65).

Size 4608 with fan on back side — Seal cage without seal, one .015" (0,38 mm) shim-gasket and cross tighten fasteners to torques specified in Table 14, (Ref. #39, 40 and 63). Seal will be added later.


Size 4608 with external backstop — Seal cage without seal, one .015" (0,38 mm) shim-gasket and cross tighten fasteners to torque specified in Table 14, (Ref. #39, 40 and 66). Seal will be added later.

4. **SHAFT ASSEMBLIES** — Where bearings and gears were not removed from the shafts, skip to Step 5. If bearings and gears were removed from the shafts, reassemble parts on the shaft per Figures 18 thru 21 as follows:

- a) To assemble gear (Ref. #1A4 or 4A4), heat gear in an oven to 275°F(135°C) and press onto the shaft & firmly against the shoulder. For Size 4608, be sure to place spacers in the proper location on shaft assemblies 2A and 4A, before pressing on the bearings.
- b) To assemble bearings, heat bearing cone in an oven to a maximum of 275°F(135°C), then slide or press them tight against the shaft shoulder or spacer.

CAUTION: Allow assembly to cool. Apply a coat of oil to the cooled bearings and gear teeth to lubricate & avoid scoring of the working surfaces.

Figure 18 — 1A Shaft Assembly




5. **DRIVE ASSEMBLY** — Turn drive housing base on work bench to allow the shaft assemblies to be lowered into the housing. Block up the housing so that when low speed shaft assembly, 4A, is in place, the threaded end of the shaft will clear the bench surface. Before assembly, inspect housing and all shaft assemblies to see that all foreign matter has been removed.

Use eye bolts to assist in lowering high speed shaft and low speed pinion assemblies (Ref. #1A, 2A and 3A) into the housing base. Lift the low speed shaft assembly (Ref. #4A) by slinging thru holes in the gear web. Assemble as follows:

- a) **SINGLE REDUCTION** — Lower high speed shaft assembly, Ref. #3A, Figure 19, into housing and tip away from other housing bores. While lowering the low speed shaft assembly, Ref. #4A, Figure 21, into housing tip high speed shaft into the gear mesh of the low speed gear as the shaft nears final position.

Figure 19 — 3A Shaft Assembly



- b) **DOUBLE REDUCTION** — Lower high speed shaft assembly, Ref. #1A, Figure 18, into housing and tip away from other bores. Simultaneously lower the intermediate shaft assembly, Ref. #2A, Figure 20, and the low speed shaft assembly, Ref. #4A, Figure 21, into the housing. As shafts approach their final position, tip the high speed shaft pinion into the high speed gear mesh, Ref. #1A4.

Figure 20 — 2A Shaft Assembly





Figure 21 — 4A Shaft Assembly



- c) Arrange the shaft assemblies to ensure that the gears are in mesh and bearing cones are in the cups. Remove the eyebolts before installing the housing cover.
- d) Place cover gasket, Ref. #32 for Sizes 4407 - 4507 & Ref. #12 for Size 4608, on housing base. Install the housing dowels into the housing base for correct alignment. Carefully lower the housing cover (using eyebolts as recommended in Section II, Step 11), without the bearing cups installed, onto the base. Tap the cover to ensure that the housing cover is fully seated on the housing base. Remove eye bolts and install cover fasteners and tighten to torques specified in Table 14.
- e) Apply film of oil to housing cover bores and bearing cups & carefully install the bearing cups into the bores as described in Step 2 above.
- f) Install seal cages without seals and covers:

DOUBLE REDUCTION DRIVES — Use the entire shim-gasket kit with the .015" (0,38 mm) shim-gasket against the housing. It is important that the .015" (0,38 mm) gasket be placed against the housing to prevent leakage. Cross tighten fasteners to torques specified in Table 14. Parts involved are as follows:

Size 4407 - 4507 — Low speed seal cage Ref. #11, 24 & 34; shaft cover Ref. #16, 26 & 36; high speed seal cage Ref. #21, 31 & 39.


Size 4608 — Low speed seal cage Ref. #22, 23 & 24; shaft cover Ref. #29, 30 & 31; high speed seal cage Ref. #38, 39 & 40.

SINGLE REDUCTION DRIVES — Install end cover, Ref. #16, 26 & 36, with one .015" (0,38 mm) shim-gasket on unused bore. For the other seal cages follow instructions from above as described for double reduction drives.

6. BEARING ADJUSTMENT

- a) For drives equipped with TA taper bushing, turn drive over onto the input housing and carefully thread bushing nut onto hollow shaft threads. Rotate the shaft to seat the cone assemblies in the bearing cups. Set up a dial indicator, Figure 22. Rotate and oscillate shaft with axial force applied in both directions to obtain the shaft axial float measurement. If no float is measured, remove bushing nut and seal cage & add shim-gaskets until float is measurable. Proceed to Step 6(c).
- b) For drives without the TA Taper bushing, insert the hollow shaft thrust plate and secure with the retaining ring as illustrated in Section I, Figure 4. Thread a bolt into the thrust plate. Set up a dial indicator on the input housing face with the indicator probe on the end of the hollow shaft. **DO NOT** indicate from the thrust plate or fastener head. Rotate and oscillate shaft with axial force applied in both directions to obtain the axial float measurement. (Upward force can be applied by prying upward on the head of the thrust plate bolt). If no float is measured, remove seal cage and add shim-gaskets between the housing flanges until float is measurable.

Figure 22



- c) If the axial float from 6(a) or (b) is greater than .010" (0,25 mm), subtract sufficient shims to obtain .001" to .010" (0,03 mm to 0,25 mm) float. Refer to Table 16 for shim thickness. Take into account the compressibility of shim-gaskets from Table 17. Reassemble and repeat Step 6(a) or (b). When float is within .001" to .010" (0,03 mm to 0,25 mm), proceed to Step 6(d).
- d) Refer to Table 15 and note the preload specified for bearings 4A1 and 4A2. Add to the upper and lower limits shown, the axial movement obtained in Step 6(c). This will indicate the thickness of shims to be removed to obtain the specified preload. For example, if the preload in Table 15 is .005 to .007 inches (0,13 mm to 0,18 mm) and the axial movement was .007 inches (0,18 mm), removal of shims with a total thickness of .012 to .014 inches (0,31 mm to 0,36 mm) will produce the desired preload. Table 16 provides shim thicknesses for each shim pack to assist in obtaining the desired results. Take into account the compressibility of shim-gaskets from Table 17.

TABLE 15 — Preload & Axial Settings - In (mm)

DRIVE SIZE	Bearings Ref. #4A1 & 4A2	Shaft & Pinion Ref. #2A3	Shaft & Pinion Ref. #1A3 or 3A3
	Bearing Preload	Axial Float	Axial Float
4407	.004-.006 (0,10-0,15)	.001-.003 (0,03-0,08)	.001-.003 (0,03-0,08)
4415	.005-.007 (0,13-0,18)		
4507	.006-.008 (0,15-0,20)		
4608	.008-.010 (0,20-0,25)		

- e) Remove seal cage Ref. #11 for Sizes 4407 - 4507; Ref. #22 for Size 4608 and remove shim-gasket(s) as determined in Step 6(d). Reattach the seal cage and tighten fasteners to torque specified in Table 14.

f) **AXIAL FLOAT ADJUSTMENT, REF. #2A3** — Remove pipe plug from center of shaft cover, Ref. #16 for Sizes 4407 - 4507 & Ref. #30 for Size 4608, and install a .375-16 x 2" or longer fastener for Sizes 4407 - 4507 and a .750-10 x 3" or longer fastener for Size 4608, thru the hole in the shaft cover into the threaded hole in the pinion shaft. Turn by hand until snug. Set up a dial indicator with the probe on the fastener head as illustrated in Figure 23. Turn the fastener in a clockwise direction, pushing and pulling the fastener to make certain the bearings are properly seated. Measure the axial float. Subtract from this reading the axial float for Ref. #2A3 shaft found in Table 15. This indicated the thickness of shims to be removed. When removing the shim(s) retain the .015" (0,38 mm) thickness against the drive housing. Retighten fasteners and recheck float. Readjust shimming, if necessary, until proper axial float is achieved (Table 15).

Figure 23





TABLE 16 — Individual Shim-Gasket Part Numbers

Ref. No.	Shim Thickness	Unit Size			
		4407	4415	4507	4608
100	...	4723120	0758580	0758587	4723196
12	.062	0329946
23	.007	1231222
	.009	0767802
	.015	0767803
	.031	0767804
24	.007	1231144	1220259	1220130	...
	.009	0767761	0757456	0757453	...
	.015	0767762	0757457	0757454	...
	.031	0767763	0757458	0757455	...
25	.015	0755904	0757460	0757460	...
26	.007	1219682	1220540	1220128	...
	.009	0755903	0757459	0755947	...
	.015	0755904	0757460	0755948	...
	.031	0755905	0757461	0755949	...
27	.015	0755904
28	.015	0755904	1220129	0757460	...
29	.007	2110776
	.009	0767805
	.015	0755904	1220129	1220129	0767806
30	.015	0755904	1220129	1220129	...
31	.007	1219682	1220540	1220128	...
	.009	0755903	0757459	0755947	...
	.015	0755904	0757460	0755948	...
	.031	0755905	0757461	0755949	...
32	.062	0344294	0334658	0344420	...
39	.007	1130518
	.009	0710702
	.015	0710703

TABLE 17 — Falk Shim-Gasket Compressibility – Inches (mm)

Thickness	New	.007 (0,18)	.009 (0,23)	.015 (0,38)	.031 (0,79)
	Compressed		.006 (0,15)	.008 (0,20)	.013 (0,33)

Figure 24



g) **AXIAL FLOAT ADJUSTMENT, REF. #1A3 or 3A3** —

Refer to Figure 24 and adjust float as follows:

Set up a dial indicator for determining axial movement of the input shaft Ref. #1A3 or 3A3. Lift upward with a twisting motion to obtain a reading.

WARNING: Cover keyway with tape to avoid lacerations to the hand.

Subtract from this reading the axial float for shaft, Ref. #1A3 or 3A3, found in Table 15. This indicates the thickness of shim(s), Ref. #31 for Sizes 4407 - 4507 and Ref. #39 for Size 4608, to be removed. When removing the shim(s), retain the .015" (0,38 mm) thick shim against the housing, Ref. #10. Retighten fasteners and recheck float. Readjust shimming, if necessary, until proper float is achieved (Table 15).

7. SEAL INSTALLATION

Seals can be installed after all bearing adjustments have been completed. Refer to Section II, Step 7, to install seals, Ref. #22 & 23 for Sizes 4407 - 4507 and Ref. #21, 37 & 64 for Size 4608. NOTE, when removing a seal cage to install a seal, be sure to replace the same shim-gaskets as removed to assure correct bearing adjustments.

8. BACKSTOP INSTALLATION

If drive will be installed on the driven equipment using a TA tapered bushing, refer to Section I, Step 7, to determine if the backstop should be installed at this time. Refer to Appendix B, for assembly instructions.

DRIVE IS READY TO INSTALL — Refer to Section I.

This Page Left Intentionally Blank

TABLE OF CONTENTS

Appendix A: Lubrication Recommendations	26
Appendix B: Backstop Installation	29
Appendix C: TA Removal Tool	33
Appendix D: Motor Mount Installation	35
Appendix E: Vertical Standpipe Installation	37
Appendix F: Modification For Non-Standard Mounting Positions	39
Appendix G: Parts Interchangeability 2000/3000 vs 4000 Series	41
Appendix H: Retaining Rings For Bushing Nuts and Thrust Plates & Tooth Combinations For Vibrations Analysis	43
Appendix J: Drive Shaft Recommendations for Tapered Drive Shafts	44
Appendix K: Drive Shaft Recommendations Using TA Taper Bushing	45
Appendix L: Drive Shaft Recommendations Using (TCB) Kit	47
Appendix M: V-Belt Guard Installation	49
Appendix N: Electric Fan Installation	51

Lubrication Recommendations

Introduction

Lubricants listed in this manual are typical products ONLY and should not be construed as exclusive recommendations. Industrial type petroleum based rust and oxidation inhibited (R & O) gear lubricants or industrial type sulfur-phosphorus extreme pressure (EP) gear lubricants are the recommended lubricants for ambient temperatures of 15°F to 125°F (-9°C to 52°C).

For drives operating outside the above temperature range, refer to the “Synthetic Lubricants” paragraphs. Synthetic lubricants can also be used in normal climates.

Carefully follow instructions on the drive nameplate, warning tags and installation manuals furnished with the drive.

Viscosity (Important)

The proper viscosity grade for R & O and EP lubricants is found in Table 5. For synthetic lubricant viscosity grades, refer to Table 4 and the “Synthetic Lubricants” paragraphs. Petroleum based lubricant selections must have a pour point at least 10°F (5.5°C) below the expected minimum ambient starting temperature.

TABLE 1 — Petroleum Based R & O Gear Lubricants †

AGMA Viscosity Grade	4	5	6	
ISO Viscosity Grade	150	220	320	
Viscosity	cSt @ 40°C	135-165	198-242	288-352
	SSU @ 100°F	626-765	918-1122	1335-1632
Manufacturer	Lubricant	Lubricant	Lubricant	
Aramco Oil Co. BP Oil Co. Chevron U.S.A., Inc. Citgo Petroleum Corp.	Amer.Ind. Oil 150 Machine Oil AW 150 Citgo Pacemaker 150	Amer.Ind. Oil 220 Energol HLP-HD 220 Machine Oil AW 220 Citgo Pacemaker 220	Amer.Ind. Oil 320 Machine Oil AW 320 Citgo Pacemaker 320	
Conoco Inc. Exxon Company, U.S.A. Houghton International, Inc. Imperial Oil Ltd.	Dectol R&O Oil 150 Teresstic 150 Hydro-Drive HP 750 Teresso 150	Dectol R&O Oil 220 Teresstic 220 Hydro-Drive HP 1000 Teresso 220	Dectol R&O Oil 320 Teresstic 320 Teresso 320	
Kendall Refining Co. Keystone Lubricants Lyondell Petrochemical (ARCO) Mobil Oil Corp. Petro-Canada Products	Four Seasons AW 150 KLC-40 Duro 150 DTE Oil Extra Heavy Harmony 150 or 150D KLC-50 Duro 220 DTE Oil BB Harmony 220 Duro 320 DTE Oil AA Harmony 320	
Phillips 66 Co. Shell Oil Co. Shell Canada Limited Texaco Lubricants	Magnus Oil 150 Morlina 150 Tellus 150 Regal Oil R&O 150	Magnus Oil 220 Morlina 220 Tellus 220 Regal Oil R&O 220	Magnus Oil 320 Morlina 320 Tellus 320 Regal Oil R&O 320	
Unocal 76 (East) Unocal 76 (West) Valvoline Oil Co	Unax RX 150 Turbine Oil 150 Valvoline AW ISO 150	Unax RX 220 Turbine Oil 220 Valvoline AW ISO 220	Unax AW 320 Turbine Oil 320 Valvoline AW ISO 320	

† Minimum viscosity index of 90. Maximum operating temperature of lubricants is 200°F (93°C)

Petroleum Based Lubricants

R & O GEAR LUBRICANTS (TABLE 1) — Industrial type petroleum based rust and oxidation inhibited (R & O) gear lubricants are the most common and readily available general purpose gear lubricants.

EXTREME PRESSURE (EP) LUBRICANTS (TABLE 2) — For highly loaded drives or for drives loaded in excess of original estimates, industrial-type petroleum extreme pressure lubricants are preferred. The EP lubricants currently recommended are of the sulphur-phosphorus type.

TABLE 2 — Petroleum Based Extreme Pressure Lubricants ★

Manufacturer	Lubricant
Aramco Oil Co. BP Oil Co. Chevron U.S.A. Inc. Citgo Petroleum Corp.	Permogear/Amogear EP Engergear EP Gear Compounds EP Citgo EP Compound
Conoco Inc. Exxon Co. U.S.A. Houghton Int., Inc. Imperial Oil Ltd.	Gear Oil Spartan EP MP Gear Oil Spartan EP
Kendall Refining Co. Keystone Lubricants Lyondell Petrochemical (ARCO) Mobil Oil Corp.	Kendall NS-MP Keygear Pennant NL Mobilgear
Petro-Canada Products Phillips 66 Co. Shell Oil Co. Shell Canada Limited	Ultima EP Philgear Omala Oil Omala Oil
Sun Oil Co. Texaco Lubricants Unocal 76 (East & West) Valvoline Oil Co.	Sunep Meropa Extra Duty NL Gear Lube AGMA EP

★ Minimum viscosity index of 90. Maximum operating temperature of lubricants is 200°F (93°C).

WARNING: EP LUBRICANTS IN FOOD PROCESSING INDUSTRY — EP lubricants may contain toxic substances and should not be used in the food processing industry without the lubricant manufacturer’s approval. Lubricants which meet USDA “H1” classification are suitable for food processing applications.

CAUTION: PETROLEUM BASED LUBRICANTS & INTERNAL BACKSTOPS — Do not use EP lubricants or lubricants with anti-wear additives or lubricant formulations including sulfur, phosphorus, chlorine, lead derivatives, graphite or molybdenum disulfides in drives equipped with internal cartridge type backstops. Some lubricants in Table 1 may contain anti-wear additives. Lubricants in Table 2 do contain several of these additives.

Synthetic Lubricants

Synthetic lubricants of the polyalphaolefin type are recommended for cold climate operation, high temperature applications, extended temperature range (all season) operation and/or extended lubricant change intervals. The proper viscosity grade of synthetic lubricant is given in Table 4.

Lubrication Recommendations

COLD CLIMATE CONDITIONS — The proper viscosity grade of synthetic lubricant is given in Table 4. Usable temperature ranges can sometimes be widened for synthetic lubricants if specific application conditions are known.

CAUTION: SYNTHETIC LUBRICANTS & INTERNAL BACKSTOPS – Synthetic lubricants may be used in drives with internal backstops operating in cold temperatures –30° to +50°F (–34° to +10°C). Select proper lubricant grade from Table 4. Mobil SHC 624 and SHC 626 provide proper backstop action under these conditions. Other synthetic lubricants may also be acceptable. DO NOT use synthetic lubricants in drives with backstops operating in ambient temperatures above 50° F (10° C).

NORMAL CLIMATE CONDITIONS — For temperatures of 15°F (–9°C) and above, use viscosity grades as recommended in Table 5 for petroleum based lubricants. Petroleum based and synthetic lubricants are suitable for normal climate conditions. Usable temperature ranges can sometimes be widened for synthetic lubricants if specific application conditions are known.

WARNING: SYNTHETIC LUBRICANTS IN FOOD PROCESSING INDUSTRY – Synthetic lubricants may contain toxic substances such as sulfur, phosphorus, chlorine, lead derivatives, graphite or molybdenum disulfides and should not be used in the food processing industry without the lubricant manufacturer’s approval. Lubricants which meet USDA “H1” classification are suitable for food processing applications.

Lubricant Changes

OIL ANALYSIS REPORT — Checking oil condition at regular intervals is recommended. In the absence of more specific limits, the guidelines listed below may be used to indicate when to change oil:

1. Water content is greater than 0.05% (500 ppm).
2. Iron content exceeds 150 ppm.
3. Silicon (dust/dirt) exceeds 25 ppm.
4. Viscosity changes more than 15%.

PETROLEUM LUBRICANTS — For normal operating conditions, change gear oils every six months or 2500 operating hours, whichever occurs first. If the drive is operated in an area where temperatures vary with the seasons, change the oil viscosity grade to suit the temperature, refer to Table 1. Lubricant suppliers can test oil from the drive periodically and recommend economical change schedules.

SYNTHETIC LUBRICANTS — Synthetic lube change intervals can be extended to 8000-10,000 hours depending upon operating temperatures and lubricant contamination. Laboratory analysis is recommended for optimum lubricant life and drive performance. Change lube with change in ambient temperature, if required. Refer to Table 4.

Grease Lubricated Seals

All drives are furnished with grease purged seals which minimize the entry of contaminants and abrasive dusts into the drive. Drives are shipped with NLGI #2 grease in the seal housing cavities unless otherwise specified.

Whenever changing oil in the drive, purge the seals with one of the NLGI #2 greases listed in Table 3.

TABLE 3 — Greases For Grease Purged Seals

[0° to 200°F (-18° to 93° C)]

Manufacturer	Lubricant
Amoco Oil Co. BP Oil Co. Chevron U.S.A., Inc. Citgo Petroleum Corp.	Amolith Grease No. 2 Energrease LS-EP2 Industrial Grease Medium Premium Lithium Grease No. 2
Conoco Inc. Exxon Company, U.S.A. Houghton Int., Inc. Imperial Oil Ltd.	EP Conolith Grease No. 2 Unirex N2 Cosmolube 2 Unirex N2L
Kendall Refining Co. Keystone Lubricants Lyondell Petrochemical (ARCO) Mobil Oil Corp.	Multi-Purpose Lithium Grease L421 Zeniplex 2 Litholine H EP 2 Grease Mobilith 22
Mobil Oil Corp. Petro-Canada Products Phillips 66 Co. Shell Oil Co.	Mobilith SHC 460 † Multipurpose EP2 Philube Blue EP Alvania Grease 2
Shell Canada Limited Sun Oil Co. Texaco Lubricants	Alvania Grease 2 Ultra Prestige EP2 Premium RB Grease
Unocal 76 (East & West) Valvoline Oil Co.	Unoba EP2 Multilube Lithium EP Grease

Some of these greases are of the EP type and may contain toxic substances not allowed in the food processing industry. If grease could contaminate the product, as in the food and drug industries, the grease should be removed. A grease that meets the USDA “H1” classification is suitable for food processing applications.

Periodically (at least every six months) depending upon the frequency and degree of contamination, purge contaminated grease from seals by slowly pumping fresh bearing grease thru the seal, **WITH HAND GREASE GUN**, until fresh grease flows out along the shaft. Wipe off purged grease.

Lubrication Recommendations

TABLE 4 — Synthetic Lubricants – Polyalphaolefin Type ‡

Ambient Temp. Range	-30 to +10°F (-34 to -12°C)	-15 to +50°F (-26 to +10°C)	0 to +80°F (-18 to +27°C)	+10 to +125°F (-12 to +52°C)	+20 to +125°F (-7 to +52°C)
AGMA Viscosity Grade	05	25	45	55	65
ISO Viscosity Grade	32	68	150	220	320
Viscosity cSt @ 40°C	28.8-35.2	61.2-74.8	135-165	198-242	288-352
Viscosity SSU @ 100°F	134-164	284-347	626-765	918-1122	1335-1632
Manufacturer	Lubricant				
Chevron U.S.A., Inc.	Clarity Synthetic PM Oil 220 Syn. Gear Lube Tegra 220 ■	...
Conoco Inc.	Syncon R & O 32	Syncon R & O 68 Syncon EP 68 ■	Syncon EP 150 ●■	Syncon R & O 220 ● Syncon EP 220 ●■	Syncon EP 320 ●■
Dryden Oil Co.	Drydene SHL Lubricant 32	Drydene SHL Lubricant 68	Drydene SHL Lubricant 150	Drydene SHL Lubricant 220	Drydene SHL Lubricant 320
Exxon Company, U.S.A.	Teresstic SHP 32	Teresstic SHP 68	Teresstic SHP 150 Spartan Synthetic EP 150 ■	Teresstic SHP 220 Spartan Synthetic EP 220 ■	Teresstic SHP 320 Spartan Synthetic EP 320 ■
Mobil Oil Corp.	SHC 624	SHC 626	SHC 629 Mobilgear SHC 150 ■	SHC 630 mobilgear SHC 220 ■	SHC 632 Mobilgear SHC 320 ■
Pennzoil Products Co.	Pennzgear SHD 32	Pennzgear SHD 68 Super Maxol "S" 68 ■	Pennzgear SHD 150 Super Maxol "S" 150 ■	Pennzgear SHD 220 Super Maxol "S" 220 ■	Pennzgear SHD 320 Super Maxol "S" 320 ■
Petro-Canada Products	Super Gear Fluid 150EP ■	Super Gear Fluid 220EP ■	Super Gear Fluid 320EP ■
Shell Oil Co.	Hyperia 220 Hyperia S 220 ■	Hyperia 320 Hyperia S 320 ■
Sun Co.	Sunoco Challenge 220 Sunoco challenge eP 220 ■	Sunoco Challenge 320 Sunoco Challenge EP 320 ■
Texaco Lubricants Co.	Pinnacle 32	Pinnacle 68	Pinnacle 150 Pinnacle EP 150 ■	Pinnacle 220 Pinnacle EP 220 ■	Pinnacle 320
Whitmore Manufacturing Co.	Decathlon 4EP ■	Decathlon 5EP ■	Decathlon 6EP ■

‡ Minimum viscosity index of 130. Consult lubricant supplier/manufacturer for maximum operating temperature.

● Minimum viscosity index of 120.

■ Extreme pressure EP lubricant (contains sulfur-phosphorus).

TABLE 5 — Viscosity Recommendations For Petroleum Based Lubricants ♦

Normal Climates					
+15 to +60°F (-9 to +16°C)		+50 to +90°F (+10 to +32°C)		+70 to 125°F (+21 to +52°C)	
ISO-VG	AGMA	ISO-VG	AGMA	ISO-VG	AGMA
150	4	220	5	320	6

♦ Consult Falk for viscosity recommendations when ambient temperatures are higher than 125°F (52°C), or when drives are operating in extremely humid, chemical, or dust laden atmospheres.

Backstop Installation — Sizes 4407/M4407 thru 4507/M4507

Introduction

The following instructions apply to INSTALLATION ONLY of internal backstops in horizontal drives, Sizes 4407 thru 4507 double reduction.

WARNING: If backstop is to be replaced, the high speed shaft must also be replaced. Refer to instructions regarding high speed shaft replacement.

Remove all external loads from drive before servicing drive or accessories, and lock out starting switch of prime mover.

Lubricant

PETROLEUM BASED LUBRICANTS — Use R & O type lubricants which do not contain anti-wear (AW) additives if the drive is equipped with an internal backstop.

CAUTION: Do not use EP lubricants or lubricants with anti-wear additives or lubricant formulations including sulfur, phosphorus, chlorine, lead derivatives, graphite or molybdenum disulfides in drives equipped with internal backstops. Refer to Appendix A for proper selection of petroleum based lubricants. Use of an improper lubricant will contribute to premature wear or malfunction of the backstop.

SYNTHETIC LUBRICANTS — Synthetic lubricants may be used in drives with internal backstops operating in cold temperatures, -30°F to +50°F (-34°C to +10°C) only. DO NOT use synthetic lubricants in drives with backstops operating above +50°F (10°C). Refer to Appendix A for proper selection of synthetic lubricants.


Backstop Application

Backstops are designed to prevent reverse rotation or backrun without backlash in applications such as conveyors, bucket elevators, fans, rotary pumps and kilns. Backstops are not approved for use on systems that are designed for handling of people such as elevators, man lifts, ski tows and ski lifts. DO NOT use a backstop as a substitute for a brake.

Indexing

DO NOT use the backstop for indexing applications. The backstop is designed to prevent reverse rotation five times or less in eight hours, with one minute or more in overrunning direction between backstopping load applications. If

Figure 1



backstopping operations are more frequent, or the time between operations is less than one minute, the backstop is classified as an indexing device and must be referred to Falk.

Installation — Sizes 4407 thru 4507

1. Drain oil from the drive. If the backstop is being added to an existing drive, remove and discard the original shaft cover, Ref. #18, and fasteners, Ref. #37, Figure 1. Size 4407, remove and discard the four short studs and replace with the longer studs, Ref. #38, provided in the kit.
2. If existing backstop is being replaced, for Sizes 4407, 4415J14 & 4507J14, remove cover, Ref. #19, backstop Ref. #5A, and appropriate spacers and retaining rings from backstop cage. For Sizes 4415J25 & 4507J25, remove entire backstop cage. Disassemble retaining rings and remove backstop. For all drives, note direction of rotation of input shaft for proper reassembly. Refer to Section II, Step 15 for shaft and backstop inspection.
3. Remove backstop, Ref. #5A1, from the kit and wipe off excess lubricant.

Figure 2






Figure 3



Backstop Installation — Sizes 4407 thru 4507

4. **SIZE 4407(Figure 2)** — Assemble backstop cage, Ref. #20, onto studs using one new .015" (0,38 mm) shim-gasket, Ref. #30, against the housing. Slide the spacer, Ref. #5A2, into the backstop cage up against the bearing cup. Align the key with the keyway in the backstop cage and gently slide the backstop into the bore while slowly rotating the shaft from the drive side of the drive. The shaft will only rotate in one direction. Check to determine if the shaft rotation is as required. If not, gently remove the backstop; turn it around, and reinsert into the bore as instructed above. Go to Step 6.

Figure 4



5. **SIZE 4415 THRU 4507** — Install dowel into cage.

- a) Size 4415J14 & 4507J14(Figure 3) — Install backstop and key into backstop cage allowing the backstop to protrude from cage 0.25" (6,4 mm). Coat spacer with grease to assist in holding the spacer against the backstop for assembly and insert into drive side of cage.
- b) Size 4415J25 & 4507J25(Figure 4) — Assemble one retaining ring in groove on backstop. Slide backstop and key into backstop cage and assemble other retaining ring on backstop to hold it in the cage.
- c) Size 4415 & 4507(All types) — Place one new .015" (0,38 mm) shim-gasket, Ref. #30, against housing. Carefully install the backstop/cage assembly on the oiled shaft extension. Rotate the high speed shaft while sliding on the assembly. The shaft will only rotate in one direction.

DO NOT FORCE OR HAMMER; this may damage the shaft or misalign the sprags.

- d) Check operation of backstop by turning input shaft in required direction of rotation by hand. If the shaft does not rotate in the required direction, remove backstop, reverse it and reinstall as instructed in preceding steps.
6. Rotate input shaft in the required direction of rotation and then reverse the rotation to lock up the backstop. Observe the position of the sprags. All Sprags must be engaged and lay in the same relative position around the shaft. If the sprags are not uniformly positioned, lightly tap the backstop cage to centralize all the sprags around the shaft and cage. If sprags cannot be uniformly positioned in this manner,


remove the backstop and run a finger around the sprags in the overrunning direction. Reinstall backstop as instructed in the preceding steps.

Check the position of the sprags several times by overrunning and locking the sprags. If all sprags move uniformly, hold the backstop in the locked position and proceed to the next assembly step.

7. Install backstop cover, shim-gasket and fasteners, Ref. #19, 29 & 38. Tighten fasteners to 825 lb-in (93 Nm) for Size 4407, and 330 lb-in (37 Nm) for Sizes 4415 - 4507.
8. Clean housing surface for rotation and warning labels. Affix the rotation indicator next to input shaft extension to indicate the free direction of rotation, Figure 5. Fill drive to oil level specified in Section I, Table 9, with oil specified in Appendix A. Check motor for correct rotation before completing connection to drive.

WARNING: Refer to Appendix A for lubricant restrictions. Use of an improper lubricant will contribute to premature wear or malfunction of the backstop.

Figure 5



Backstop Installation — Size 4608/M46008

Introduction

The following instructions apply to INSTALLATION ONLY of an external backstop (Model B1F, Size 20) in a horizontal drive, Size 4608 double reduction drive. This backstop is sold only as an accessory for new or existing Falk drives. Do not use for any other application without written approval from The Falk Corporation.

The backstop is designed to operate during overrunning within a speed range of 400 to 1800 rpm and for creep drives between 100 and 400 rpm no more than one hour per month. For continuous speeds less than 400 rpm or greater than 1800 rpm, refer application to Falk. The backstop can operate successfully on slope mounted applications up to a maximum shaft axis tilt of 6° from horizontal; refer to Falk for other mountings.

CAUTION: To prevent damage to backstops due to incorrect motor shaft rotation at start up, couplings are NOT assembled when drives are furnished with backstops.

After completing the electrical connection, check motor and drive shaft rotations. Then complete alignment and assembly of coupling.

WARNING: DO NOT use Falk pawl type backstops in tandem. Refer to Falk all applications involving the need for two or more backstops in one system.

DO NOT use backstops for systems that are designed for the handling of people such as elevators, man lifts, ski tows and ski lifts.

DO NOT use the backstop as a substitute for a brake.

The backstop and normal associated equipment (shaft, pulleys, etc.) involve moving parts, therefore consult local, state, OSHA and ANSI safety codes for proper guarding of rotating members and possible pinch points.

If Backstop slippage occurs, DO NOT operate. Install a new backstop before resuming operation.

Installation

1. Lock out power source and remove external load from system.
2. Clean the backstop bore and the shaft on which the backstop will be mounted. Remove and clean shaft key and set aside.

CAUTION: Refer to direction of rotation arrow on backstop. Before installation make certain that the direction of rotation is correct. Check backstop size on nameplate and make certain it is correct.

3. Slide backstop onto shaft and torque arm pin. The backstop must slip onto shaft. DO NOT hammer backstop on shaft. Allow clearance between backstop anchor lug and torque arm pin, Figure 6. Allow clearance at torque arm pin for the extreme float limits of the shaft, Figure 7. Install key after aligning keyways.

4. Install spring pin or other locking device to hold backstop onto torque arm pin.
5. Check free and locked rotation of backstop. If satisfactory, stake key to the shaft, Figure 8.

Figure 6




Figure 7





Figure 8



Backstop Installation — Size 4608

Maintenance

Only Type B1F backstops are furnished with grease-purged seals which minimize the entry of taconite and other abrasive dusts into the backstop. Unless specifically ordered otherwise, Type B1F backstops are furnished with NLGI #2 bearing grease in the seal housing cavities.

WARNING: DO NOT fill cavities with grease if application is in the food or drug industry, where grease could contaminate the product.

To make use of this feature, pump NLGI #2 bearing grease into the seal housing cavity through the seal grease fitting. Periodically (monthly) depending upon the frequency and degree of contamination, purge contaminated grease from seal by pumping fresh bearing grease through the bearing cage until it flows out along the shaft. Wipe off purged grease.

Service & Removal

WARNING: DO NOT attempt to service or remove backstop before locking out power source and removing load.

Backstops must not be dismantled or repaired. Backstops are non-serviceable components. Replace damaged backstops with a new Factory tested backstop.

Remove backstop by applying axial force to the hub of the backstop only.

TA Removal Tool

Introduction

The TA removal tool (Patent Pending) offers a positive method for removing a TA Taper equipped Quadrive from the driven shaft. This method uses the torque multiplying characteristic of the drive to separate the drive from the bushing and driven shaft.

The removal tool is available in kit form suitable for use with Sizes 4407 thru 4608. The kit can be ordered from your Falk distributor by specifying "TA Removal Kit - Part 0769407".
NOTE: Use of this tool requires a minimum axial clearance ("M" shown in Figure 1 and Table 1), from the seal cage stud.

CAUTION: DO NOT modify the tool in any way OR use it in another manner except to loosen the bushing nut as instructed herein.

Figure 1




TABLE 1 — Minimum Tool Clearance - In (mm)

Drive Size	M Dimension
4407	5.12 (130,0)
4415	5.12 (130,0)
4507	5.38 (136,7)
4608	5.12 (130,0)

Preparation For Removal


WARNING: Always "lock out" prime mover before working on the Quadrive.

1. Quadrive shafts, input and output, must be free to rotate.
 - a) Remove any external load on the driven shaft.
 - b) Remove belts from input shaft sheave.
 - c) Remove the backstop (if so equipped) when:
 - Type J05 input shaft rotation indicator is counter-clockwise.
 - Type J14 & J25 input shaft rotation indicator is clockwise.
 Refer to Section II — Step 10, for backstop removal instructions.

WARNING: DO NOT disconnect the drive from its tie rod until the removal process is completed. In addition, the drive must be supported during removal process. Use a sling around the motor mount or as recommended in SECTION I, Step 6, Page 6. Be sure to take up the slack in the sling before proceeding.

2. Loosen the setscrew on the O.D. of the bushing nut. Remove the most convenient seal cage nut and lock washer from the stud. Figure 2.

Figure 2



3. Select the proper adapter from the tool kit. (Adapters are marked with the Quadrive Size and part number). Thread the appropriate adapter onto the stud and apply tightening torque from Table 2.

TABLE 2 — Adapter Tightening Torque

Drive Size	Part Number	Torque (lb-in.)
4407	2111960	1296 (146)
4415	2111960	1296 (146)
4507	2111961	1440 (163)
4608	2111960	1296 (146)

4. Mount the removal tool as illustrated in Figure 3 or 4. It is generally preferable to install the tool in a position where it's weight will tend to keep it engaged into the nut. Rotate the input shaft until the tool hook engages one of the slots in the nut.

TA Removal Tool

Figure 3





Figure 4



Removal Of Quadrive

- Use a spanner wrench to apply torque through the input shaft keyway (Type J05 clockwise; Types J14 or J25 counter-clockwise) to loosen the bushing nut.

WARNING: Never use the prime mover to produce the torque needed. This could result in severe personal injury or damage to the equipment.

CAUTION: To avoid damage to the drive or the removal tool, DO NOT exceed the H.S. shaft torque values listed in Table 3.

NOTE: The nut will rotate freely for approximately 180° as it moves from the locked to the removal position. Resistance will indicate that unseating is occurring. Turn until the nut and bushing are completely free. Now, prepare the drive for lifting by disconnecting the tie rod at the drive end.

- ALTERNATE METHOD** — Torque may be applied to the sheave or sprocket mounted on the input shaft.

**TABLE 3 — Maximum Torque - H.S. Shaft
lb-in (Nm)**

Drive Size	Drive Reduction		
	J05	J14	J25
4407	10120 (1 143)	3630 (410)	2000 (226)
4415	10830 (1 224)	4040 (456)	2200 (249)
4507	...	4460 (504)	2460 (278)
4608	2860 (323)


Motor Mount Installation

Introduction

The Falk Equi-Poised Motor Mount is an all-steel weldment that bolts directly to the steel frame of Falk Shaft Mounted (Type JR), Flange Mounted (Type JF) and Screw Conveyor (Type JSC) Drives, as shown in Figure 1.

This modern design provides a simple means of tensioning V-belts with adjusting screws. The motor base plate is pre-drilled for rerated NEMA standard foot-mounted motors within the rated capacity of the drive.

Figure 1



Assembly Instructions


From Figure 2, determine which assembly is required. Drives are shown assembled in the 3 o'clock position, high speed shaft relative to low speed shaft. They can also be mounted in the 6, 9 and 12 o'clock positions after the motor mounts are assembled.

WARNING: Remove all external loads from drive before servicing drive or accessories.

Consult applicable local and national safety codes for proper guarding of rotating members.

Figure 2


STANDARD ASSEMBLIES



A3
(3 o'clock)




C3
(3 o'clock)



D3
(3 o'clock)

Letter = Motor Mount Position, Clock = Drive H.S.S. Position



OSHA type guard when specified. Dimensions to suit components.

1. Assemble motor mount bracket to drive.
 - a) Sizes 4407 thru 4507 — Remove housing cover fasteners and bolt motor mount bracket to housing using longer fasteners provided.
 - b) Size 4608 — Attach bracket to pads provided on seal cage.
2. Assemble rear support bracket to drive.
 - a) Sizes 4407 thru 4507JR and 4407JF, JSC (Figure 3) — Remove nuts and lock washers from seal cage studs and attach rear support bracket.
 - b) Sizes 4415, 4507 and 4608JF (Figure 4) — Attach rear support to flange using mounting bolts furnished by user (Furnished by Falk for Size 4608JF).
 - c) Size 4608JR (Figure 3) — Attach rear support bracket to seal cage pads using fasteners provided.

Figure 3 Sizes:
4407 thru 4507JR
4407JF & JSC
4608JR





Figure 4 Sizes:
4415 thru
4608JF



Motor Mount Installation

TABLE 1 — Fastener Size and Tightening Torque lb-in (Nm) ★

DRIVE SIZE	Motor Mount to Housing		Support to Seal Cage		Support to Motor Mount		Support to Flange	
	Size	Torque	Size	Torque	Size	Torque	Size	Torque
4407	.500-13	825 (93)	.750-10	3960 (447)	.500-13	825 (93)	.750-10	3960 (447)
4415	.500-13	825 (93)	.750-10	3960 (447)	.500-13	825 (93)	1.25-7	12600 (1 424)
4507	.500-13	825 (93)	.875-10	6400 (723)	.500-13	825 (93)	1.25-7	12600 (1 424)
4608	.500-10	2940 (332)	.750-10	2940 (332)	.500-10	2940 (332)	.750-10	2940 (332)

★ All fasteners are Grade 5.

3. Assemble support bracket to motor mount bracket — Use the fasteners provided. Torque all fasteners to values listed in Table 1.
4. Assemble base plate to motor mount bracket — Assemble adjusting screws to motor mount bracket and base plate with jam nuts above and below the base plate.
5. Mount motor — Position motor on base plate so that all mount holes are in alignment. Install and tighten motor fasteners.
6. Mount sheaves and V-belt — Mount sheaves as close to the drive and motor housing as possible. Hold a straight edge across the faces of the two sheaves to obtain correct alignment. Adjust V-belt to the tension recommended by the belt manufacturer by turning the adjusting screws evenly. When the required tension is reached, tighten lock nuts. DO NOT over tighten belts. Over tightening belts reduces belt and bearing life.

Vertical Standpipe Installation

Introduction

The following instructions apply to the installation of standpipe kits to standard drives mounted for vertical operation (high speed shaft up or down). Drawings are representative of this series of drives and may not agree in exact detail with all drive sizes.

NOTE: Vertical shaft drives, when filled to the proper oil level, are completely full of oil.

High Speed Shaft Down — Figure 1.

1. After installing the drive per the Owners Manual installation instructions, determine which of the upper side plug locations on the drive will provide the best location for the standpipe, observing clearance required to remove dipstick (Dimension D, Table 1). Discard the air vent. When the air vent location is not used for the standpipe, relocate the pipe plug from the selected standpipe location to the air vent location. Recoat pipe plug threads with Permatex #3 or equivalent sealant before reinstalling.

TABLE 1 — Dimensions – Inches (mm)

Drive Size	A	B	C	D	
H.S. Shaft Down					
4407	0.75 (19,1)	1.25 (31,8)	1.75 (44,5)	21.76 (552,7)	
4415	0.90 (22,9)	1.40 (35,6)	1.90 (48,3)	19.62 (498,3)	
4507	0.92 (23,4)	1.42 (36,1)	2.00 (50,8)	21.28 (540,5)	
H.S. Shaft Up					
4407	0.75 (19,1)	1.25 (31,8)	1.75 (44,5)	24.30 (617,2)	
4415	1.06 (26,9)	1.56 (39,6)	2.00 (50,8)	17.70 (449,6)	
4507	1.02 (25,9)	1.52 (38,6)	2.00 (50,8)	18.30 (464,8)	
H.S. Shaft Up or Down					
Drive Size	Output Speed	A	B	C	D
4608	10 to 53	1.75 (44,5)	2.25 (57,2)	2.75 (69,9)	9.50 (241,3)
	54 to 67	2.00 (50,8)	2.50 (63,5)	3.00 (76,2)	9.50 (241,3)
	68 to 75	2.75 (69,9)	3.25 (82,6)	3.75 (95,3)	9.50 (241,3)

2. Coat all pipe threads of kitted parts with Permatex #3 or equivalent sealant.
3. Assemble kitted parts to the drive as illustrated in Figure 1 and then secure the standpipe with an external support to maintain its vertical position.
4. Carefully measure Dimension X as illustrated in Figure 1.
5. From Table 1 :
X + A equals oil level "Full" mark.
X + B equals oil level "Low" mark.
X + C equals dipstick length.
6. Scribe Dimensions X + A and X + B on the dipstick as illustrated in Figure 1. Make measurements from the felt pad in the dipstick cap.
7. Lightly chisel permanent oil level marks on the scribed lines and cut the dipstick to the length marked. File end of dipstick smooth.
8. Install magnetic drain plug (furnished) in oil drain location.
9. Remove the oil filler plug. Add oil until the oil level reaches the "Full" mark on the dipstick. Coat the filler plug (not vented) with Permatex #3 or equivalent sealant and replace it.
10. Filler plug must always be removed to relieve entrapped air before checking oil level.

High Speed Shaft Up — Figure 2.

1. After installing the drive per the Owners Manual installation instructions, determine which of the lower four side plug locations on the drive will provide the best location for the standpipe, observing clearance required to remove dipstick (Dimension D, Table 1). Discard the air vent. When the air vent location is not used for the standpipe, relocate the pipe plug from the selected standpipe location to the air vent location. Recoat pipe plug threads with Permatex #3 or equivalent sealant before reinstalling.

Figure 1





Figure 2



Vertical Standpipe Installation

2. Coat all pipe threads of kitted parts with Permatex #3 or equivalent sealant.
3. Assemble kitted parts to drive as illustrated in Figure 2 and then secure the standpipe with an external support to maintain its vertical position.
4. Carefully measure Dimension X as illustrated in Figure 2.
5. From Table 1:
 - X + A equals oil level "Full" mark.
 - X + B equals oil level "Low" mark.
 - X + C equals dipstick length.
6. Scribe Dimensions X + A and X + B on the dipstick as illustrated in Figure 1. Make measurements from the felt pad in the dipstick cap.
7. Lightly chisel permanent oil level marks on the scribed lines and cut the dipstick to the length marked. File end of dipstick smooth.
8. Install magnetic drain plug (furnished) in oil drain location.
9. Remove the oil filler plug. Add oil until the oil level reaches the "Full" mark on the dipstick. Coat the filler plug (not vented) with Permatex #3 or equivalent sealant and replace it.
10. Filler plug must always be removed to relieve entrapped air before checking oil level.

Modifications For Non-Standard Mounting Positions

Instructions

For non-standard mountings, modify drives as illustrated below and on Page 40 to assure satisfactory lubrication. For applications that exceed the limits shown, for drives that are both rotated AND tilted and for drives with backstops, consult Falk.


NOTE: For Size 4608, refer to Falk.

CAUTION: Inadequate lubrication will cause damage.

When replacing a pipe plug (P) with a street elbow (E), insert the plug in the elbow (E/P). When replacing a pipe plug (P) with a street elbow (E), pipe nipple (N) and a pipe cap (C), discard the pipe plug. Kits consist of parts for an oil expansion chamber. Pipe fittings and kits tabulated on Page 40 are available from Falk. Pipe fittings may also be purchased locally. Use galvanized pipe fittings.

Remove all pipe plugs and coat them and the added parts, with Permatex #3D or equivalent to prevent leakage. Install parts as illustrated to suit the mounting position. The air vent must be in the top of the drive or in the kit standpipe. Fill drives with oil to the level indicated by the letter "L" in the following drawings.

Standard Drive Mounting Limits




The 10° Max rotation illustrated at the left applies to standard 3, 6, 9 & 12 o'clock mountings. For higher limits, follow the instructions at the left and the drawings below. (6 o'clock illustrated)

CODE
B — Reducing Bushing N — Nipple
C — Cap P — Pipe Plug
E — Street Elbow STD — No Modifications
L — Oil Level

Horizontal Drive Modifications for 10 to 20° Drive Rotation


10 to 20° Clockwise Rotation

3 O'Clock — CW Rotation




4407 = KIT 738471 & .750 x .500 B
4415 & 4507 = KIT 738471 & 1.25 x .500 B

6 O'Clock — CW Rotation




4407 = .750 E/C & .750 x 1.375 N
4415 & 4507 = 1.250 E/C & 1.250 x 1.625

9 O'Clock — CW Rotation



4407 = KIT 738471 & .750 x .500 B
4415 & 4507 = KIT 738471 & 1.25 x .500 B


12 O'Clock — CW Rotation



4407 = .750 E/C & .750 x 1.375 N
4415 & 4507 = 1.25 E/C & 1.25 x 1.625


10 to 20° Counterclockwise

3 O'Clock — CCW Rotation




4407 = .750 E/C & .750 x 3.00 N
4415 = 1.250 E/C & 1.250 x 3.00 N
4507 = 1.250 E/C & 1.250 x 3.50 N

6 O'Clock — CCW Rotation



4407, 4415 & 4507 = STD


9 O'Clock — CCW Rotation



4407 = .750 E/C & .750 x 1.375 N
4415 & 4507 = 1.250 E/P

* This oil level applies when only a street elbow with a pipe plug is used.


12 O'Clock — CCW Rotation



4407, 4415 & 4507 = STD

Modifications For Non-Standard Mounting Positions

Standard Drive Mounting Limits



The limits illustrated at the left applies to standard 3, 6, 9 & 12 o'clock mountings. For higher limits, follow the instructions on Page 39 and the drawings below. (6 o'clock illustrated)

NOTE: For Size 4608, refer to Falk.

CODE
C — Cap
E — Street Elbow
L — Oil Level
N — Nipple
P — Pipe Plug
STD — No Modifications

Standard Pipe Fittings ★ — Inches


.750-14NPT	Falk No.	1.25-11.5 NPT	Falk No.
.750 Street Elbow	915253	1.25 Street Elbow	915255
.750 Cap	914804	1.25 Cap	914806
.750 x 1.375 Nipple	915824	1.25 x 1.625 Nipple	915882
.750 x 3 Nipple	915836	1.25 x 2.5 Nipple	915885
.750 x .500 Bushing	914652	1.25 x 3 Nipple	915886
		1.25 x 3.5 Nipple	915897
		1.25 x .500 Bushing	914656

★ Kits: Falk Nos. 738471 . . . Oil expansion chamber parts. All pipe fittings are galvanized.


Horizontal Drive Modifications for Inclined H.S. Shaft

H.S. Shaft Inclined 20 to 30° Up


3 O'Clock H.S.S. Up




6 O'Clock H.S.S. Up



9 O'Clock H.S.S. Up




12 O'Clock H.S.S. Up




H.S. Shaft Inclined 5 to 30°


3 O'Clock H.S.S. Down




6 O'Clock H.S.S. Down



9 O'Clock H.S.S. Down



12 O'Clock H.S.S. Down



Parts Interchangeability 3000 vs 4000 Series

The parts listed in the Table below are unique to the superseded Series 3000 drives. All other parts for Series 3000 drives are

Parts Interchangeability 3000 vs 4000 Series

Ref No.	Part Description	Drive Size		
		3407	3415	3507
Housing Components — J05, J14 & J25				
11	Seal Cage	0344291
12	Flange/Seal Housing	0344292
13	Seal Cover	4723118	4723143	4723162
14	Shaft Cover	4723116	4723141	4723161
18	Shaft Cover	1190359
20	Backstop Cage	1219671
22	Seal	0912763
100	Shim-Gasket Kit – Includes Ref. #24 - 32	0758573
Rotating Elements — J05				
3A	Shaft Assembly – Includes Ref. #3A1 - 3A4	0758567	0758574	0758581
3A3	Pinion & Shaft	4723123	4723148	4723169
Rotating Elements — J14				
1A	Shaft Assembly With 1A4 Gear	4723131
1A	Shaft Assembly Without 1A4 Gear	0758568
1A2	Bearing	0921872
Rotating Elements — J25				
1A	Shaft Assembly With 1A4 Gear	4723136	...	4723177
1A	Shaft Assembly Without 1A4 Gear	0758569	...	0758583
1A2	Bearing	0921871
1A3	Pinion & Shaft	4723181
Rotating Elements — J14 & J25				
2A	Shaft Assembly – Includes Ref. #2A1 - 2A4	0758570	0758577	0758584
2A3	Pinion & Shaft	4723139	4723159	4723184
Rotating Elements — J05, J14 & J25				
4A	Shaft Assembly - Includes Ref #4A1 - 4A7	0758571	0758578	0758585
4A1	Bearing	0921605
4A2	Bearing	0921605
4A3	Hollow Shaft - Includes Ref. #4A5 & 4A7	0758572	0758579	0758568
4A4	Gear	1219669	1220254	1220140

Parts Interchangeability Drive Size 608 vs 4608

The parts listed in the Table below are the ONLY parts interchangeable between Sizes 608J and 4608J. All other parts are unique to the specific drive Size 608J or 4608J. Refer to Section II, Table 11, for Size 4608J parts list.

Parts Interchangeability

Ref. No.	Part Description	Drive Size
		4608
Housing Components		
17	Air Vent	0720000
37	Seal	0912758
38	Seal Cage	4723186
63	Seal Cage	4723187
64	Seal	0912757
65	Shaft Cover	0284960
66	Seal Cage	4723188
67	Yoke	4723194
80	Fastener Kit - Includes Ref. #11, 13, 18, 24, 31, & 40	4723195
Bearings		
1A1	Bearing	0921751
1A2	Bearing	0921752
Accessories		
5A	Backstop	0755442
6A1	Fan	4723214
6A2	Bushing	4723215
6A3	Guard	4723173
6A4	Grill	4723216
6A10	Shaft Guard	4723217
6A11	Deflector	0294866

Retaining Rings For Bushing Nuts And Thrust Plates

JR — Retaining Rings for Bushing Nuts

Drive Size	Manufacturer Part Number
4407	Truarc N5000-650
4415	Eaton IN725
4507	Truarc N5000-775
4608	Truarc N5000-900

JF & JSC — Retaining Rings for Thrust Plate Kits

Drive Size	Manufacturers Part Number
4407	Truarc N5000-500
4415	Eaton IN-550
4507	Truarc N5000-600
4608	Truarc N5000-725

Seal Housing Lip Seal For Type JSC

Type JSC — Seal Housing Lip Seal

Drive Size	Falk Part No.	Manufacturer Part No.
		Chicago Rawhide
4407	2913658	39320

Tooth Combinations For Vibrations Analysis

Type J05 — Tooth Combinations

Drive Size	Exact Ratio	Pinion Ref. #3A3	Gear Ref. #4A4
4407	4.938	16	79
4415	5.077	13	66
4507	4.929	14	69
4608	NA


Type J14 — Tooth Combinations

Drive Size	Exact Ratio	Input		Output	
		Pinion Ref. #1A3	Gear Ref. #1A4	Pinion Ref # 2A3	Gear Ref. #4A4
4407	13.78	24	67	16	79
4415	13.61	25	67	13	66
4507	13.46	26	71	14	69
4608	NA

Type J25 — Tooth Combinations

Drive Size	Exact Ratio	Input		Output	
		Pinion Ref. #13	Gear Ref. #1A4	Pinion Ref. #2A3	Gear Ref. #4A4
4407	25.02	15	76	16	79
4415	25.07	16	79	13	66
4507	24.33	16	79	14	69
4608	24.48	22	89	20	121

Drive Shaft Recommendations for Tapered Drive Shafts



Dimensions – Inches (mm) ★

DRIVE SIZE	Keyway		D • + .000, - .005 (+0,00, - 0,13)	DA	LA ± .030 (± .76)	LB + .000, - .010 (+ .000, - .250)	LC + .040, - .000 (+ 1.02, - .00)	LD	LE	MD ■	S	T Min.	Key		
	W ‡	L ± .010 (± 0,25)											W	H	L
4407	1.000 (25,40)	7.000 (177,80)	4.925 (125,10)	5.175 (131,45)	0.500 (12,70)	4.374 (111,10)	9.250 (234,95)	5.25 (133,4)	2.25 (57,2)	2.45 (62,2)	1.000-8	2.75 (69,8)	1.000	0.750	6.00
4415	1.250 (31,75)	8.750 (222,25)	5.455 (138,56)	5.767 (146,48)	1.000 (25,40)	4.864 (123,54)	10.925 (277,50)	6.00 (152,4)	2.50 (63,5)	2.85 (72,4)	1.250-7	2.50 (63,5)	1.250	0.875	7.50
4507	1.250 (31,75)	9.000 (228,60)	6.003 (152,48)	6.327 (160,71)	1.000 (25,40)	5.368 (136,35)	12.020 (305,31)	7.00 (177,8)	2.50 (63,5)	3.10 (78,7)	1.250-7	2.50 (63,5)	1.250	0.875	7.75
4608	1.500 (38,10)	11.500 (292,10)	7.277 (184,84)	7.617 (193,47)	1.000 (25,40)	6.061 (153,95)	13.875 (352,42)	8.50 (215,9)	3.00 (76,2)	3.21 (81,5)	1.250-7	3.00 (76,2)	1.500	1.500	10.00

★ Dimensions are for reference only and are subject to change without notice unless certified.

‡ Inch keyway width tolerances are as follows: over .500" (12,70) to & including 1.000" (25,40) = +.0030" (+0,076), -.0000" (-0,000), over 1.000" (25,40) to & including 1.500" (38,10) = +.0035" (+0,089), -.0000" (-0,000). Inch keyway depth tolerance is +.010" (+0,25), -.000" (-0,00).

● Straight diameter is used to aid in measurement and manufacture of the keyway.

■ Dimension "MD" will vary slightly depending on degree of axial compression during installation and manufacturing tolerances.

Drive Shaft Recommendations Using TA Taper Bushing

INTRODUCTION — These instructions are for use when a flange mounted 4407-4608JF drive is to be used and the manufacture of a tapered drive shaft is not feasible. For JF tapered drive shaft recommendations, see Appendix J. Use this appendix to retrofit existing applications or for outfitting new installations. Parts required are the drive, TA Taper bushing and a special thrust plate kit. **NOTE:** A special thrust plate kit with long fastener and extra retaining ring is required. The standard J thrust plate kit will not work. Specify the special thrust plate kit by part number. See Table 1.

TABLE 1 — Special Thrust Plate Kit Part No.

JF Drive Size	Part No.	JF Drive Size	Part No.
4407	0778780	4507	0778782
4415	0778781	4608	0778783

This appendix will allow the use of a straight drive shaft with the tapered bushing (without spanner nut) on flange mounted applications. Provided are dimensions (Table 5) for shaft recommendations and instructions for the installation and removal of the assembly. All bushing bore sizes, which are available in the standard Quadrive, are possible with this setup.

FIGURE 2 — 4407-4608JF drives are furnished with a flange adapter installed. The hollow shaft of the drive has a tapered bore which accepts the tapered bushing. When the bushing is drawn into the taper, a clamping force is applied to the drive shaft. The drive shaft is drawn into the hollow shaft via a fastener in the thrust plate. The bushing seats against a shoulder on the driven shaft and is drawn into the drive with the shaft. Removal is accomplished by using a jackscrew in the thrust plate and forcing the drive shaft out of the drive. The retaining ring in the drive shaft assures that the bushing will be removed along with the shaft.

DRIVE SHAFT RECOMMENDATIONS — The recommendations for the drive shaft consist of two major features. The first is the shoulder which must be provided in the location shown in Figure 2. This shoulder provides the backing necessary to draw the bushing into the taper. A permanently fixed shoulder must be provided in order for this design to be effective. The shoulder may be a welded collar or an integral step. **SET COLLARS ARE NOT ACCEPTABLE.** A retaining ring may be used, in the driven shaft, to provide the shoulder, but stress concentrations occur at the groove and therefore shaft stresses must be checked. The second major feature on the shaft is the retaining ring groove in the shaft end. This feature is recommended to ensure positive removal of the bushing when the drive shaft is removed from the drive. The threaded hole in the end of the drive shaft accepts the thrust plate fastener.

WARNING: Lock out power source and remove all external loads from system before servicing drive or accessories.

INSTALLATION PROCEDURE — With the drive shaft manufactured per the recommendations shown, and the bushing selected for the proper shaft diameter, remove and discard the retaining ring and spanner nut from the bushing assembly.

4407JF — Use of the tapered bushing requires that the flange of the bushing be removed to clear the adapter, Figure 2. A flangeless bushing is available for the 3.4375" (87 mm)

diameter shaft only.

ALL JF DRIVES — Slide the bushing (flange end first) onto the drive shaft until it contacts the shoulder on the shaft. Insert the key through the bushing and into the drive shaft keyway. Install the retaining ring into the groove in the drive shaft. Bring the drive into position, line up the hollow shaft keyway with the key and slide the bushing and drive shaft into the hollow shaft bore.

Attach the drive to the mounting surface with fasteners (not provided). Refer to Table 2 for fastener size and tightening torque. Assemble the thrust plate and retaining ring into the counterbore in the hollow shaft. Insert the thrust plate fastener through the thrust plate and thread into the drive shaft end. Tighten to the torque given in Table 3. Install all covers and guards.

REMOVAL PROCEDURE — Remove hollow shaft cover. Remove the thrust plate fastener, retaining ring and thrust plate from the hollow shaft. Refer to Table 4 and select a backing bolt and flat washer and install them into the drive shaft as illustrated in Figure 1. The head of the backing bolt provides a working surface for the removal bolt. Reinsert the thrust plate and retaining ring into the hollow shaft and select a removal bolt from Table 4. Thread the removal bolt into the thrust plate until it contacts the backing bolt head.




TABLE 2 — JF Drive – Foundation Fastener & Tightening Torque (Non-Lubricated Fasteners)

DRIVE SIZE	Fastener Size & Grade	Max Tightening Torque lb-ft (Nm)
4407	.750-10UNC, Grade 5	245 (332)
4415	1.250-7UNC, Grade 5	1050 (1424)
4507	1.250-7UNC, Grade 5	1050 (1424)
4608	1.500-6UNC, Grade 5	1842 (2497)

Tighten the removal bolt to the torque indicated in Table 4. (If the thrust plate rotates in the shaft, align the slot in the plate with the hollow shaft keyway and insert a screw driver or piece of key stock to prevent rotation of the plate). After torquing the bolt, as instructed, strike the bolt sharply with a hammer and retorquing the bolt if separation of the drive from the shaft did not occur. Repeat this procedure, retorquing the bolt after each blow, until separation occurs.

Drive Shaft Recommendations Using TA Taper[®] Bushing

Figure 2




TABLE 3 — Thrust Plate Fastener Data (Non-Lubricated Fasteners)

DRIVE SIZE	Fastener Size & Grade	Max. Tightening Torque lb-ft (Nm)	Min Thread Depth Inches (mm)
4407	1.000-8UNC x 5.50, Grade 8	792 (1073)	2.75 (69,8)
4415	1.250-7UNC x 6.00, Grade 8	1596 (2164)	3.00 (76,2)
4507	1.250-7UNC x 6.00, Grade 8	1596 (2164)	3.00 (76,2)
4608	1.250-7UNC x 8.00, Grade 8	1596 (2164)	3.50 (88,9)

TABLE 4 — Removal & Backing Bolt Size and Tightening Torque

DRIVE SIZE	Removal Bolt Size & Min Length – Inches	Max Tightening Torque lb-ft (Nm)	Backing Bolt Size & Max Length – Inches
4407	1.125-7UNC x 3.00	742 (1006)	1.000-8UNC x 2.50
4415	1.500-6UNC x 3.75	1842 (2497)	1.250-7UNC x 2.75
4507	1.500-6UNC x 3.75	1842 (2497)	1.250-7UNC x 2.75
4608	1.500-6UNC x 3.75	1842 (2497)	1.250-7UNC x 2.75

TABLE 5 — Dimensions For Largest Bore Bushing – Inches (mm) ★

DRIVE SIZE	Thrust Plate Kit †	Thrust Plate Part No.	A ± 0.010 (±0,25)	B ± 0.030 (±0,75)	C ‡	D •	DA ■	DB Min.	Retaining Ring ♦				Keyway *			S	T Min.
									Groove		Spir O Lox		W	H	L Min.		
									F	G	Mfg. No.	Max. O.D.					
4407	TP4407JF	0778780	8.160 (207,26)	8.500 (215,90)	1.384 (35,15) 1.037 (26,34)	5.250 (133,35)	4.4375	4.750 (120,65)	4.059 (104,25) 4.071 (103,95)	0.120 (3,05) 0.125 (3,18)	RSN-425	4.688	1.000	0.5000	7.750 (196,85)	1.000-8 (69,8)	
4415	TP4415JF	0778781	10.100 (256,54)	10.375 (263,52)	0.867 (22,02) 0.520 (13,21)	...	4.9375	5.250 (133,35)	4.616 (117,18) 4.604 (116,95)	0.079 (2,00) 0.084 (2,13)	RS-475	5.125	1.250	0.6250	9.563 (242,90)	1.250-7 (76,2)	
4507	TP4507JF	0778782	10.440 (265,18)	10.750 (273,05)	0.617 (15,67) 0.269 (6,83)	...	5.4375	5.750 (146,05)	5.114 (129,85) 5.100 (129,55)	0.079 (2,00) 0.084 (2,13)	RS-525	5.688	1.250	0.6250	9.875 (250,82)	1.250-7 (76,2)	
4608	TP4608JF	0778783	12.530 (318,26)	13.000 (330,20)	2.639 (67,03) 2.292 (58,22)	...	6.5000	7.000 (177,80)	5.993 (152,35) 5.977 (151,95)	0.174 (4,41) 0.182 (4,60)	RSN-625	6.813	1.500	0.7500	12.625 (320,68)	1.250-7 (88,9)	

★ For metric drive shafts or bushing bores smaller than the maximum, provide the retaining ring groove per manufacturers' recommendations, keyway appropriate for the shaft diameter, and DB minimum of 0.300" (7.62 mm) larger than the bushing bore to provide adequate backing.

† Kit consists of: thrust plate, thrust plate fastener, hollow shaft retaining ring and drive shaft retaining ring.

‡ The range for C dimensions is the variation which may occur due to axial compression and manufacturing tolerances.

• The D dimension is the recommended minimum bore which clears the TA Taper bushing flange.

■ Shaft diameter tolerances are per AGMA as follows: over 2.50" to & including 4.00" = +.000", -.006"; over 4.00" to & including 6.00" = +.000", -.007"; over 6.00" to & including 7.00" = +.000", -.008". Metric drive shafts are to be based on h10 tolerances.

Drive Shaft Recommendations Using (TCB) Kit

INTRODUCTION — These instructions are for use when a screw conveyor 4407JSC drive is to be used and the following conditions exist: Falk standard or 316 stainless steel JSC tapered drive shafts can not be used due to special extension dimensions or materials; or manufacturing a special tapered drive shaft is not feasible. Use this appendix to retrofit existing applications or for outfitting new installations where the above conditions warrant. For tapered shaft recommendations, see Appendix J.

This appendix will allow the use of a straight (non tapered) drive shaft with a special bushing conversion kit on screw conveyor applications. The bushing conversion kit may also be used on flange mounted 4407JF applications where the Falk JSC seal housing is to be used as the mounting flange. This kit provides one bushing bore per drive size as shown in Table 4. Provided in this appendix are dimensions for drive shaft recommendations and instructions for the installation and removal of the assembly.

FIGURE 2 — The hollow shaft of the drive has a tapered bore which accepts the tapered bushing. When the bushing is drawn into the taper, a clamping force is applied to the drive shaft. The drive shaft is drawn into the hollow shaft via a fastener in the thrust plate. The bushing seats against a shoulder on the drive shaft and is drawn into the drive with the shaft. Removal is accomplished by using a jackscrew in the thrust plate and forcing the drive shaft out of the drive. The retaining ring in the drive shaft assures that the bushing will be removed along with the shaft.

DRIVE SHAFT RECOMMENDATIONS — The recommendations for the drive shaft consist of two major features. The first is the shoulder which must be provided in the location shown in Figure 2. This shoulder provides the backing necessary to draw the bushing into the taper. A permanently fixed shoulder must be provided in order for this design to be effective. The shoulder may be a welded collar or an integral step. SET COLLARS ARE NOT ACCEPTABLE. A retaining ring may be used in the drive shaft, to provide the shoulder, but stress concentrations can occur at the groove and therefore shaft stresses must be checked. The second major feature on the shaft is the retaining ring groove in the shaft end. This feature is recommended to ensure positive removal of the bushing when the drive shaft is removed from the drive. The threaded hole in the end of the drive shaft accepts the thrust plate fastener.

WARNING: Lock out power source and remove all external loads from system before servicing drive or accessories.

INSTALLATION PROCEDURE — With the shaft manufactured per the recommendations shown, proceed as follows:

The seal housing may be assembled to the drive before or after the drive shaft is installed into the drive, but if the seal housing is installed to the drive first, the lip type seal (if used) must be installed from the extension end.

Slide the bushing (large end first) onto the drive shaft until it contacts the shoulder on the shaft. Insert the key through the bushing and into the drive shaft keyway. Install the retaining ring into the groove in the drive shaft. Line up the keyway in the drive hollow shaft with the key in the drive shaft and slide shaft/bushing assembly into the hollow shaft. Attach the seal housing to the drive with the fasteners provided. Tighten fasteners to torque given in Table 1. Assemble the thrust plate and retaining ring into the counterbore in the hollow shaft. Insert the thrust plate fastener through the thrust plate and

thread into the drive shaft end. Tighten to the torque given in Table 2. Install all covers and guards.

REMOVAL PROCEDURE — Remove low speed shaft input end cover. Remove the thrust plate fastener, retaining ring and thrust plate from the hollow shaft. Refer to Table 3 and select a backing bolt and flat washer and install them into the drive shaft as illustrated in Figure 1. The head of the backing bolt provides a working surface for the removal bolt. Reinsert the thrust plate and retaining ring into the hollow shaft and select a removal bolt from Table 3. Thread the removal bolt into the thrust plate until it contacts the backing bolt head. Tighten the removal bolt to the torque indicated in Table 3. (If the thrust plate rotates in the shaft, align the slot in the plate with the hollow shaft keyway and insert a screwdriver or piece of key stock to prevent rotation of the plate). After torquing the bolt, as instructed, strike the bolt sharply with a hammer and retorquer the bolt if separation of the drive from the shaft did not occur. Repeat this procedure, retorquing the bolt after each blow, until separation occurs.




TABLE 1 — Seal Housing Fastener Tightening Torque (Non-Lubricated Fasteners)

DRIVE SIZE	Fastener Size & Grade	Max. Tightening Torque lb.-ft.(Nm)
4407	.750-10UNC	330 (447)

TABLE 2 — Thrust Plate Fastener Data (Non-Lubricated Fasteners)

DRIVE SIZE	Fastener Size & Grade	Max. Tightening Torque lb-ft (Nm)	Min Thread Depth Inches (mm)
4407	1.000- 8UNC x 5.50, GR.8	792 (1074)	2.75 (69,8)

Drive Shaft Recommendations Using (TCB) Kit

Figure 2




TABLE 3 — Removal & Backing Bolt Size and Tightening Torque

DRIVE SIZE	Removal Bolt Size & Min Length – Inches	Max Tightening Torque lb-ft (Nm)	Backing Bolt Size & Max Length – Inches
4407	1.125- 7UNC x 3.00	742 (1006)	1.000- 8UNC x 2.50

TABLE 4 — Dimensions – Inches (mm)

Taper Conversion Bushing Kit †	(TCB) Kit Part No.	A ± 0.010 (± 0,25)	B ± 0.030 (± 0,75)	C ‡	DA •	DB ■ +0.000, -0.003 (+0,00, -0,08)	Retaining Ring ♦			Keyway *			S	T Min.	Weld/Integral Flange		
							Groove		Mfg. No.	Max. O.D.	W	H			L Min.	U	V
							F	G									
TCB4407J-3.438	0786823	7.655 (194,44)	9.500 (241,30)	1.879 (47,73) 1.552 (39,42)	3.4375	3.938 (100,03)	3.263 3.251	0.103 0.108	Spir O Lox RSN-343	...	0.875	0.4375	9.250 (234,95)	1.000-8	2.75 (69,9)	1.500 (38,10)	...

† Kit consists of: Bushing, thrust plate, fastener, key, retaining ring, and hardware.

‡ The range of C dimension is the variation which may occur due to axial compression and manufacturing tolerances.

• Shaft diameter tolerances are per AGMA as follows: over 2.50" to & including 4.00" = +.000", - .006".

■ If a lip type seal is used, a 32rms finish is recommended.

♦ Smalley retaining rings may be used instead of Spir O Lox by substituting WSM for RSN.


* Inch keyway width tolerances are as follows: over .500" to & including 1.000" = +.0030", -.0000"; 1.000". Inch keyway depth tolerance is +.010", -.000".

OSHA V-Belt Guard Installation For Drives Without Shaft Fan


WARNING: Consult applicable local and national safety codes for proper guarding of rotating members.

WARNING: Lock out power source and remove all external loads from drive before servicing drive or accessories.


1. ASSEMBLE MOTOR MOUNT AND MOTOR TO DRIVE AS INSTRUCTED IN APPENDIX D




4. ASSEMBLE THREADED RODS TO BACKPLATE & MOUNT SLOT COVER(S) AS REQUIRED




2. ASSEMBLE BELT GUARD BRACKETS TO MOTOR MOUNT




5. MOUNT BELT DRIVE AS INSTRUCTED IN APPENDIX D



3. ASSEMBLE BACKPLATE TO BRACKETS



6. MOUNT COVER AND APPLY WARNING LABEL




OSHA V-Belt Guard Installation For Drives With Shaft Fan


WARNING: Consult applicable local and national safety codes for proper guarding of rotating members.

WARNING: Lock out power source and remove all external loads from drive before servicing drive or accessories.

1. ASSEMBLE MOTOR MOUNT AND MOTOR TO DRIVE AS INSTRUCTED IN APPENDIX D




4. ASSEMBLE THREADED RODS TO BACKPLATE & MOUNT SLOT COVER(S) AS REQUIRED




2. ASSEMBLE GUARD MOUNTING BRACKET & ADAPTER TO GUARD BACKPLATE


A9 MOTOR MOUNT POSITION




5. MOUNT BELT DRIVE AS INSTRUCTED IN APPENDIX D



3. ASSEMBLE BACKPLATE WITH ADAPTER TO SHROUD



6. MOUNT COVER




Electric Fan Installation

Introduction

The following instructions apply to the installation of the electric fan. The sump temperature switch is provided as a standard feature.

The sump temperature switch features dual settings for two independent single-pole, double-throw circuits. Only one circuit is used to control the fan. The remaining circuit may be used to control a warning light, an alarm, or a motor shutdown switch if the temperature setting is exceeded. The sump temperature switch wiring diagram is given in Figure 1.

Figure 1



Refer to Figure 2 for electric fan, temperature switch and bulb well standard mounting locations. The bulb well houses the sump temperature probe. These mounting locations are based on drive mounting position.

Figure 2

ELECTRIC FAN, TEMP. SWITCH & BULB-WELL STANDARD LOCATIONS (BASED ON DRIVE MOUNTING POSITION)

DRIVE WITH MOTOR MOUNT			DRIVE W/O MOTOR MOUNT
A3	C3	D3	3 O'CLOCK
B6	D6	A6	6 O'CLOCK
C9	A9	B9	9 O'CLOCK
D12	B12	C12	12 O'CLOCK


Assembly Instructions

WARNING: Consult applicable local and national safety codes for proper guarding of rotating members.

Lock out power source and remove all external loads from drive before servicing drive or accessories.

1. Drain oil from the drive.
2. **ELECTRIC FAN PANEL REWORK** — The holes in the electric fan panel must be enlarged to accommodate the fasteners used to mount the electric fan to the shroud. Align the fan panel to the shroud. Locate and drill four 0.4375" (12 mm) diameter clearance holes in line with the pre-drilled holes in the shroud.
3. Insert four 1.25" (32 mm) cap screws through the fan mounting holes in the shroud with the threaded portion of the cap screw away from the drive. Secure the cap screws to the shroud with flat washer (2 washers for 4407) and nut, see Figure 3.


Figure 3



4. Secure the sump temperature switch to the switch mounting bracket. Attach the switch and mounting bracket to the fan shroud, refer to Figure 2 for location.
5. Install the temperature probe bulb well in the designated drain hole as shown in Figure 4. Refer to Figure 2 for bulb well location.


CAUTION: Sump temperature probe must be located below oil level.

Figure 4



6. Mount the shroud on drive using spacers and hardware, see Figure 5.

Figure 5



7. Place the temperature probe in bulb well and secure capillary to the shroud by using one or two cable straps to remove extra slack, refer to Figure 4.
CAUTION: Do not crimp capillary.
8. Install split nut in the bulb well to retain the temperature probe.
9. Sump temperature switch settings:
 - a) Remove the two screws and cover from the top of switch to reveal the sump temperature switch setting wheels. Set the low circuit to turn the electric fan on at 140°F (60°C). Set the high circuit at 210°F (99°C) to engage alarm or main motor cutout.
 - b) Remove the four screws and cover from the front of the sump temperature switch to reveal the differential setting wheels. Rotate the wheels to the full clockwise position as viewed from the top of the switch. This is the maximum temperature differential setting of 15°F (9°C). Replace the cover and four screws.
10. Fill drive to oil level specified in Section I with oil specified in Appendix A.
11. Position the electric fan panel on the remaining threaded portion of the cap screws from Step 2 and secure it to the shroud with four locknuts, see Figure 3.
12. Remove the condensation plug from the bottom of the electric fan.
13. Place the button plug in the shroud, see Figure 5.
14. Connect the electric fan to the power source per local and national electrical codes.