


DIMENSIONS X and Y



INSTRUCTIONS

The following instructions for Sizes 1020 thru 1050 also apply to Sizes 20 thru 50, respectively. Refer to Service Manual 428-410 for complete installation instructions of Type T41 couplings and Manuals 428-410 & 428-410.1 for Type T44 clutches. Refer to the O.D. of the hub or drive plate for the coupling size. Prepare the controlled torque assembly for operation as follows:

1. Set Distance X for all springs to the value indicated by the triangle (▲) in the applicable chart.
2. Break in the friction segments as instructed in Manual 428-410.
3. Determine Distance X for the required slip torque.
4. Tighten each adjusting nut approximately two turns in sequence until Distance X is reached.
5. Do NOT set Distance X to less than the minimum value indicated by the diamond (◆).


IMPORTANT

Overload slippage causes friction faces to wear and increases Distance X. Readjust, as required, to the original Distance X to maintain the required slip torque. Replace friction segments when Distance Y approaches .050 inches.


SPRING DATA

COUPLING SIZE	Spring	Part No.	DIMENSIONS — INCHES		
			Wire Dia.	Outside Dia.	Free Height
1020	Inner	1178283	.055	.42	.70
	Outer	1178291	.078	.63	.70
1030	Inner	1178284	.072	.44	.96
	Outer	1178292	.109	.72	.96

SIZE 1020 Standard Slip Torques




SIZE 1030 Standard Slip Torques



▲ Set Distance X to this value for breaking in of friction segments.
◆ Do NOT set Distance X to less than this minimum value.

SPRING ADJUSTMENT CHARTS FOR STANDARD SLIP TORQUES

DIMENSIONS X and Y



INSTRUCTIONS

The following instructions for Sizes 1020 thru 1050 also apply to Sizes 20 thru 50, respectively. Refer to Service Manual 428-410 for complete installation instructions of Type T41 couplings and Manuals 428-410 & 428-410.1 for Type T44 clutches. Refer to the O.D. of the hub or drive plate for the coupling size. Prepare the controlled torque assembly for operation as follows:

1. Set Distance X for all springs to the value indicated by the triangle (▲) in the applicable chart.
2. Break in the friction segments as instructed in Manual 428-410.
3. Determine Distance X for the required slip torque.
4. Tighten each adjusting nut approximately two turns in sequence until Distance X is reached.
5. Do NOT set Distance X to less than the minimum value indicated by the diamond (◆).


IMPORTANT

Overload slippage causes friction faces to wear and increases Distance X. Readjust, as required, to the original Distance X to maintain the required slip torque. Replace friction segments when Distance Y approaches .050 inches.


SPRING DATA

COUPLING SIZE	Spring	Part No.	DIMENSIONS — INCHES		
			Wire Dia.	Outside Dia.	Free Height
1040	Inner	1178285	.093	.55	1.38
	Outer	1178293	.139	.88	1.38
1050	Inner	1178286	.101	.58	1.32
	Outer	1178294	.149	.96	1.32

SIZE 1040 Standard Slip Torques



SIZE 1050 Standard Slip Torques



- ▲ Set Distance X to this value for breaking in of friction segments.
 ◆ Do NOT set Distance X to less than this minimum value.